

Festo_Positioning_Basic library – Point to Point PTP

Commissioning of a selected system with the Festo_Positioning_Basic library is explained step by step, so that it's successfully integrated into the user program.

FPosB

TitleFesto_Positioning_Basic library – Point to Point
Version 1.30
Document no. 100102
Originalen
AuthorFesto

Last saved 15.06.2021

Copyright Notice

This documentation is the intellectual property of Festo SE & Co. KG, which also has the exclusive copyright. Any modification of the content, duplication or reprinting of this documentation as well as distribution to third parties can only be made with the express consent of Festo SE & Co. KG.

Festo SE & Co KG reserves the right to make modifications to this document in whole or in part. All brand and product names are trademarks or registered trademarks of their respective owners.

Legal Notice

Hardware, software, operating systems and drivers may only be used for the applications described and only in conjunction with components recommended by Festo SE & Co. KG.

Festo SE & Co. KG does not accept any liability for damages arising from the use of any incorrect or incomplete information contained in this documentation or any information missing therefrom.

Defects resulting from the improper handling of devices and modules are excluded from the warranty.

The data and information specified in this document should not be used for the implementation of safety functions relating to the protection of personnel and machinery.

No liability is accepted for claims for damages arising from a failure or functional defect. In other respects, the regulations with regard to liability from the terms and conditions of delivery, payment and use of software of Festo SE & Co. KG, which can be found at www.festo.com and can be supplied on request, shall apply.

All data contained in this document do not represent guaranteed specifications, particularly with regard to functionality, condition or quality, in the legal sense.

The information in this document serves only as basic information for the implementation of a specific, hypothetical application and is in no way intended as a substitute for the operating instructions of the respective manufacturers and the design and testing of the respective application by the user.

The operating instructions for Festo products can be found at www.festo.com/sp.

Users of this document (application note) must verify that all functions described here also work correctly in the application. By reading this document and adhering to the specifications contained therein, users are also solely responsible for their own application.

Table of contents

1 PTP..... 5

1 PTP

The prerequisite for this section is a configured, enabled and homed system.
The operating mode is selected for the desired function.


Visualisation	Codesys
	<pre> g_stOut.stSW.xError = FALSE; g_stOut.stSW.xConfigDone = TRUE; g_stOut.stSW.xIsPortal = TRUE; g_stOut.stSW.xReadyToEnable = TRUE; g_stOut.stSW.xEnabled = TRUE; g_stOut.stSW.xHomed = TRUE; g_stOut.stSW.arxMotorPresent[0] = 1; g_stOut.stSW.arxMotorPresent[1] = 1; g_stOut.stSW.arxMotorPresent[2] = 1; </pre>

Table 1: Labelling

The procedure used to this end can be found in sections/ApplicationNotes XXX.

The PTP mode is very well suited for positioning the system from point to point within the working range. Each position is specified individually and travel to them is initiated by means of the start command.

	Visualisation	Codesys
1	The dynamics values can be changed during operation, but not when travel is taking place. PTP Dyn Vel 10.00 Acc 100.00 Dec -100.00 PTP Pos X 100.000 Y 100.000 Z 20.000 U 0.000 V 0.000 W 0.000 Start Halt Quick Stop Abort Ack M Function Ack All M Functions Enable Step Mode Next Step EnablePathCorrection NoAbortByEMCYErr	<pre> g_stIn.stDynJogInch.lVel := 10; g_stIn.stDynJogInch.lAcc := 100; g_stIn.stDynJogInch.lDec := -100; g_stIn.stDynJogInch.lJerk := 0; </pre>

5	Positioning has been successfully completed when Motion Complete is reported back, as long as no errors have occurred. The “isMoving” and “Busy” outputs are inactive.
	☒ Config Done ☒ Is Portal ☒ ReadyTo Enable ☒ Enabled ☒ Homed ☐ Resetting ☐ Busy ☐ Step Mode Active ☐ Step Done ☐ IsMoving ☐ Halt Active ☐ Interrupt Active ☐ Aborted ☒ Motion Complete ☐ Path Corr Active ☐ M_Active ☐ Error ☒ IPO Done <pre> g_stOut.xError = FALSE; g_stOut.stSW.xIsMoving = FALSE; g_stOut.stSW.xBusy = FALSE; g_stOut.stSW.xMotionComplete = TRUE; </pre>
6	The start command is reset.
7	During the course of travel, positioning motion can be suspended with the “Halt” command. The position set is still active. As soon as the halt command is deactivated, positioning is continued.

PTP Dyn	
Vel	10.00
Acc	100.00
Dec	-100.00

PTP Pos	
X	10.000
Y	100.000
Z	10.000
U	0.000
V	0.000
W	0.000

Start
Halt
Quick Stop
Abort
Ack M Function
Ack All M Functions
Enable Step Mode
Next Step
EnablePathCorrection
NoAbortByEMCYErr




```
g_stIn.stCW.xStart := FALSE;
```

PTP Dyn	
Vel	10.00
Acc	100.00
Dec	-100.00

PTP Pos	
X	10.000
Y	100.000
Z	10.000
U	0.000
V	0.000
W	0.000

Start
Halt
Quick Stop
Abort
Ack M Function
Ack All M Functions
Enable Step Mode
Next Step
EnablePathCorrection
NoAbortByEMCYErr

```
g_stIn.stCW.xHalt := TRUE;
```

8	If “Halt” is active during positioning, the system is in the “Busy” status with active “HaltActive”. “IsMoving” is inactive. “Motion Complete” is not reported back.	
		<pre> g_stOut.stSW.xIsMoving = FALSE; g_stOut.stSW.xHaltActive = TRUE; g_stOut.stSW.xBusy = FALSE; g_stOut.stSW.xMotionComplete = FALSE; </pre>
9	A travel command can also be aborted. As opposed to the “Halt” command, the position set is aborted in this case. However, the position set should first be suspended with the halt command if possible, and then aborted.	
		<pre> g_stIn.stCW.xStart := TRUE; g_stIn.stCW.xAbort := TRUE; </pre>
10	Abortion is reported back in the status display.	
		<pre> g_stOut.stSW.xAborted = TRUE; </pre>