

**YJKP - Adjustment force sensor**

Step by step description to adjust the force sensor of the YJKP

YJKP

Title .....YJKP - Adjustment force sensor  
Version ..... 1.10  
Document no. .... 100205  
Original .....en  
Author .....Festo  
  
Last saved ..... 04.02.2019

## Copyright Notice

This documentation is the intellectual property of Festo AG & Co. KG, which also has the exclusive copyright. Any modification of the content, duplication or reprinting of this documentation as well as distribution to third parties can only be made with the express consent of Festo AG & Co. KG.

Festo AG & Co KG reserves the right to make modifications to this document in whole or in part. All brand and product names are trademarks or registered trademarks of their respective owners.

## Legal Notice

Hardware, software, operating systems and drivers may only be used for the applications described and only in conjunction with components recommended by Festo AG & Co. KG.

Festo AG & Co. KG does not accept any liability for damages arising from the use of any incorrect or incomplete information contained in this documentation or any information missing therefrom.

Defects resulting from the improper handling of devices and modules are excluded from the warranty.

The data and information specified in this document should not be used for the implementation of safety functions relating to the protection of personnel and machinery.

No liability is accepted for claims for damages arising from a failure or functional defect. In other respects, the regulations with regard to liability from the terms and conditions of delivery, payment and use of software of Festo AG & Co. KG, which can be found at [www.festo.com](http://www.festo.com) and can be supplied on request, shall apply.

All data contained in this document do not represent guaranteed specifications, particularly with regard to functionality, condition or quality, in the legal sense.

The information in this document serves only as basic information for the implementation of a specific, hypothetical application and is in no way intended as a substitute for the operating instructions of the respective manufacturers and the design and testing of the respective application by the user.

The operating instructions for Festo products can be found at [www.festo.com](http://www.festo.com).

Users of this document (application note) must verify that all functions described here also work correctly in the application. By reading this document and adhering to the specifications contained therein, users are also solely responsible for their own application.

# Table of contents

- 1     Components/Software used ..... 4**
- 2     Application description..... 5**
- 3     Prerequisites ..... 6**
  - 3.1   IO control / WebVisu ..... 6
  - 3.2   Host control..... 7
  - 3.3   Additional hardware and setup ..... 9
- 4     Adjusting the force sensor ..... 10**

## 1 Components/Software used

Type/Name	Version Software/Firmware	Date of manufacture
Servo press kit YJKP	General	--
Application software YJKP (GSAY-A4-F0-Z4-1.3.3)	V1.3.3	--
Firmware controller (CECC-X)	V3.4.6	--
Firmware motor controller (CMMP-AS)	V4.0.1501.2.4	--

Table 1.1: 1 Components/Software used

## 2 Application description

This application note shows step by step how to use the adjustment functionality of the YJKP both with IO control (WebVisu) and via host.


It is used to compare the characteristics of the force sensor with reference values or to reset them to factory settings.

It's not necessarily needed to adjust the sensor to have a fully functional YJKP.

### 3 Prerequisites

#### 3.1 IO control / WebVisu

The control highness in the system settings is set to WebVisu.




Required inputs:

- Manual mode (X3.1)
- Terminate press process (X3.5)
- Servo press activation (X17.4.2)


Required outputs:

- Servo press ready for operation (X20.1.1)
- Servo press activated (X20.5.1)
- **NOT** Homing required (X20.2.1)



### 3.2 Host control

The control highness in the system settings is set to Host.



Two function blocks are needed.

#### 1. FB\_Connect

Required inputs:

- xEnable := true;
- enTargetComMode := 0;

Required outputs:

- xActive = true;
- enActualComMode = 0;
- xConnected = true;




Figure 3-7: FB\_Connect

## 2. FB\_Manual

Required inputs:

- xEnable := true;
- xEnableSystem := true;
- xAbort := true;

Required outputs:

- xActive = true;
- xSystemEnabled = true;
- xSystemHomed = true;
- xInOperation = false;





Table 3-30: FB\_Manual



### 3.3 Additional hardware and setup

To adjust the sensor of the YJKP you'll need an additional external (calibrated) sensor with the possibility to display or read its actual force value.



## 4 Adjusting the force sensor


1. Open the webvisu of the YJKP, login and go to the commissioning tab.

In this case the status of “Adjust force sensor” is **red**.

This only indicates, that default values are loaded.

It's not a must to do the adjustment. The YJKP will also work with default values and status “**red**”.

2. Start the adjustment of the force sensor with “Adjust force sensor”.




3. The adjustment of the force sensor is done with a two point adjustment.  
This means you need two different force values, which are optimally as far apart as possible.

Example in this application note:

Value 1: 25N

Value 2: 730N

4. To start a new adjustment, go over this screen with “Next”.



**Adjustment force sensor**

You can adjust the force sensor or reset the adjustment of the force sensor to the factory settings.

**Adjust:** Push button **[Next]** to adjust the force sensor.

**Reset:** Push button **[Reset adjustment]** to reset the adjustment of the force sensor to the factory settings.

**Reset adjustment**

**Cancel** **Next**

Commissioning Program Operation Diagnosis


Not ready

Logout

5. Step 1/3:  
In this step you first have to apply a small force value to the YJKP.

Use the jogging functionality to move the YJKP on the external sensor. By changing the velocity you can fine-tune your desired value.

Min. force in that case doesn't mean the minimum value of the force range of the YJKP, but just the lower force value of the two force values required for the adjustment.



**Adjustment force sensor**

**Step 1/3: Adjust min. force**

Move the servo press to the min. force and enter the force value of the external force sensor in the field below. Afterwards confirm the input and transfer of the corresponding current value with click on button "Next".

Measured force value

**Back** **Cancel** **Next**

Commissioning Program Operation Diagnosis

Ready

Logout

**Released**

**Actual force**  
15.12 N

**Actual position**  
11.88 mm

**Actual velocity**  
0.00 mm/s

**Tare**  
☐ Tare  
Offset

**Motion:**  
☐ Absolute  
☐ Relative

**Jog**  
☒ **-**  
☒ **+**  
Velocity

Using a host PLC, you can jog the YJKP with the FB\_manual and the following inputs:

- enTargetPosMode := 0;
- rTargetMotionVelocity := >0;
- xJogPos or xJogNeg := true;

outputs:

- enActualPosMode = 0;
- rActualMotionVelocity = rTargetMotionVelocity;

FB_Manual	
stSystemDataRef	xActive
xEnable	xSystemEnabled
xEnableSystem	xSystemIsHomed
xStartHoming	xInOperation
xAbort	xSystemError
xQuitSystemError	xTared
xTare	rActualOffsetForceSensor
rTargetOffsetForceSensor	enActualPosMode
enTargetPosMode	rActualMotionVelocity
rTargetMotionVelocity	rActualMotionPositionDistance
rTargetMotionPositionDistance	rActualPosition
xMove	rActualForce
xStopMove	rActualVelocity
xJogPos	xError
xJogNeg	wERRORID

Table 3-30: FB\_Manual

- Use the jogging functionality to move the YJKP on the external sensor. Apply a small force to the external sensor and read the value.  
Example: 25N



7. Enter the force value of the external force sensor in the marked field.  
The actual force value in the WebVisu has no meaning at this point.  
Proceed with “Next”.

### Adjustment force sensor

**Step 1/3: Adjust min. force**

Move the servo press to the min. force and enter the force value of the external force sensor in the field below.  
Afterwards confirm the input and transfer of the corresponding current value with click on button “Next”.

Measured force value

25.00 N

Actual force:

25 N

Back
Cancel
Next

Released

**Actual force**  
15.12 N

**Actual position**  
11.88 mm

**Actual velocity**  
0.00 mm/s

**Tare**

☐ Tare

Offset 0.00 N

**Motion:**

☐ Absolute

☐ Relative

☒ Jog

-  
+

Velocity 0.50 mm/s

Commissioning
Program
Operation
Diagnosis

Ready

Logout

## 8. Step 2/3:

In the second step you have to apply a high force value to the YJKP.

Use the jogging functionality to move the YJKP on the external sensor. By changing the velocity you can fine-tune your desired value.

Max. force in that case doesn't mean the maximum value of the force range of the YJKP, but just the higher force value of the two force values required for the adjustment.

**Adjustment force sensor**

Step 2/3: Adjust **max. force**

Move the servo press to the max. force and enter the force value of the external force sensor in the field below. Afterwards confirm the input and transfer of the corresponding current value with click on button "Next".

Measured force value

**Released**

**Actual force**  
716.53 N

**Actual position**  
12.25 mm

**Actual velocity**  
0.02 mm/s

**Tare**

☐ Tare

Offset

**Motion:**

☐ Absolute

☐ Relative

☒ Jog

Velocity

**Back** **Cancel** **Next**

Commissioning Program Operation Diagnosis

Ready

Logout

Using a host PLC, you can jog the YJKP with the FB\_manual and the following inputs:

- enTargetPosMode := 0;
- rTargetMotionVelocity := >0;
- xJogPos or xJogNeg := true;

outputs:

- enActualPosMode = 0;
- rActualMotionVelocity = rTargetMotionVelocity;

FB_Manual	
stSystemDataRef	xActive
xEnable	xSystemEnabled
xEnableSystem	xSystemIsHomed
xStartHoming	xInOperation
xAbort	xSystemError
xQuitSystemError	xTared
xTare	rActualOffsetForceSensor
rTargetOffsetForceSensor	enActualPosMode
enTargetPosMode	rActualMotionVelocity
rTargetMotionVelocity	rActualMotionPositionDistance
rTargetMotionPositionDistance	rActualPosition
xMove	rActualForce
xStopMove	rActualVelocity
xJogPos	xError
xJogNeg	wErrorID

Table 3-30: FB\_Manual

9. Use the jogging functionality to move the YJKP on the external sensor. Apply a high force to the external sensor and read the value.  
Example: 730N



10. Enter the force value of the external force sensor in the marked field. The actual force value in the WebVisu has no meaning at this point. Proceed with "Next".

### Adjustment force sensor

Step 2/3: Adjust **max. force**

Move the servo press to the max. force and **enter the force value of the external force sensor** in the field below.  
Afterwards confirm the input and transfer of the corresponding current value with click on button "Next".

Measured force value 730.00 N

Actual force:  
**730 N**

[Back](#)
[Cancel](#)
[Next](#)

[Logout](#)

Commissioning

Program Operation Diagnosis

Ready

**Released**

Actual force  
716.53 N

Actual position  
12.25 mm

Actual velocity  
0.02 mm/s

**Tare**

☐ Tare

Offset 0.00 N

**Motion:**

☐ Absolute

☐ Relative


☒ Jog

Velocity 0.50 mm/s

## 11. Step 3/3:


In the last step you'll see a summary of the entered values and the new graph in comparison to the old values.

Finish the adjustment with "Save".



## 12. As soon as an adjustment is saved, the status "Adjustment force sensor" turns to green.

There is no check for reasonability of the entered values.





13. It's possible to reset the adjustment and load the default values again. Just enter again the adjust force sensor function and press the button "Reset adjustment". It will directly jump into step 3/3, where you can save the default values.

The screenshot shows the 'Adjustment force sensor' screen in the Festo software. The title 'Adjustment force sensor' is at the top left. The main text area contains instructions: 'You can adjust the force sensor or reset the adjustment of the force sensor to the factory settings.' and 'Adjust: Push button [Next] to adjust the force sensor.' Below this, a highlighted instruction states: 'Reset: Push button [Reset adjustment] to reset the adjustment of the force sensor to the factory settings.' A blue button labeled 'Reset adjustment' is centered and highlighted with a red rectangle. At the bottom right of the main area are 'Cancel' and 'Next' buttons. The bottom navigation bar includes 'Commissioning' (active), 'Program', 'Operation', and 'Diagnosis'. A status indicator shows a red dot and 'Not ready'. On the far right, there are icons for a globe, a question mark, and a user profile with the text 'Logout'.

FESTO

### Adjustment force sensor

You can adjust the force sensor or reset the adjustment of the force sensor to the factory settings.

Adjust: Push button [Next] to adjust the force sensor.

Reset: Push button [Reset adjustment] to reset the adjustment of the force sensor to the factory settings.

Reset adjustment

Cancel Next

Commissioning Program Operation Diagnosis

● Not ready

Logout