


Application Note

FESTO

Safety Sub-function
SDI Category 1, up to PL c
PUS Category 1, up to PL c



Application Note
SDI, PUS, Category
1, up to PL c

Title Application Note SDI, PUS, Category 1, up to PL c
Version 1.0
Document number (TSHQ) 100235
Original German
Author Festo
Last date of saving 14.05.2019

Legal Notice

In the following, the “Festo AG & Co.KG” is designated as “Festo”.

This Example circuit is not binding. This example circuit outlines a possible solution for a sample application and makes no claim of completeness, especially with regard to configuration and equipment, as well as any eventualities for your actual application. The Example circuit is not a customised solution, it merely offers assistance with typical task assignments.

The values stated in the Example circuit are partly assumptions and assessments which do not replace a detailed examination based on EN ISO 13849 part 1 and 2.

The actual characteristic values that can be obtained (especially PL, PFH_D, category, DC, MTT_D, CCF) depend on the components used, as well as their conditions of use in the actual application.

The example circuit does not relieve you of the obligation to carry out a risk assessment and a validation of the specific application and to ensure the adherence to all specifications, especially the EC Machinery Directive 2006/42/EG. As the user, you are responsible for your specific application and for the correct operation of the described products.

Festo does not accept any liability for damages arising from the use of any incorrect or incomplete information contained in this documentation or any information missing therefrom. This equally applies to defects resulting from improper handling of devices and modules. In addition, all liability, with the exception of intent or gross negligence on the part of Festo, for damages arising due to non-adherence of the specifications of the EC Machinery Directive 2006/42/EG is also rejected.

The information in this document is in no way intended as a substitute for the operating instructions of the respective manufacturers or the design and testing of the application by the user. The operating instructions for products from Festo can be found at www.festo.com. Users of this document must themselves verify that all the functions described herein also work correctly in the application. Even after examining this document and using the specifications contained herein, users are nevertheless solely responsible for their own application.

Otherwise, all stipulations concerning liability included in the terms and conditions of delivery, payment and use of software from Festo, which can be found at www.festo.com and can be supplied on request, apply.

This document is only suitable for persons with sufficient expertise for machine safety based on EN ISO 12100 and EN ISO 13849. In addition, the following qualifications are required in the project team:

- Specialist in pneumatics
- Specialist in electrical engineering
- Specialist for the programming of control systems and safety switching devices

Copyright Notice

This documentation is the intellectual property of Festo, which also holds the exclusive copyright. Any modification of the content, duplication or reprinting of this documentation, as well as distribution to third parties, is only permissible with the express consent of Festo.

Festo reserves the right to make modifications to this document in whole or in part. All brand and product names are trademarks or registered trademarks of their respective owners.

© (Festo AG & Co.KG, D - 73734 Esslingen, 2019)

Internet: www.festo.com

E-Mail: service_international@festo.com

Table of Content

- 1 Example Circuits 4**
- 1.1 SDI at Stopping and PUS with 5/2 Directional Control Valve, Category 1, up to PL c 5
 - 1.1.1 Circuit Diagram 5
 - 1.1.2 Components..... 5
 - 1.1.3 Description..... 6
 - 1.1.4 Safety Considerations 7
- 2 Literature 7**

1 Example Circuits

- The circuits specified in this document are principle circuits which cannot be complete due to their clarity and scope.
- The abbreviations used for the safety sub-functions refer to the definitions in VDMA 24584 [1] for pneumatics:
 - SDI: Safe Direction
 - PUS: Prevention unexpected start-up
- Category and PL according EN ISO 13849-1 [2]
- The circuits and the procedure described are recommendations which do not exclude other possibilities.
- Due to the wide variety of possible 5/2 directional control valves, no valve type and part numbers can be given in this document. When selecting valves, make sure that the selected valves have the following characteristics:
 - Valve function: 5/2 monostable
 - Type of actuation: electrical
 - Type of reset: mechanical spring
 - Sealing principle: soft
 - Type of piloting: piloted
 - Pilot air supply: internal or external
 - Duty cycle: 100%.
 - Well-tried components according to EN ISO 13849-1 and the relevant basic and well-tried safety principles have been observed.
 - B10 value required for the calculation of the $MTTF_D$ value must be available.

Important note

- In addition, further design features and requirements may exist, which must be determined depending on the application.


1.1 SDI at Stopping and PUS with 5/2 Directional Control Valve, Category 1, up to PL c

SDI and PUS according VDMA 24584 [1] and category 1, up to PL c according EN ISO 13849-1 [2].

1.1.1 Circuit Diagram





According to EN ISO 14118 enclosed pressurized air shall be marked and shall be provided with a possibility for manual pressure release.



1.1.2 Components

Component	Type	Description / Part Number / Remarks	Qty.	Mssr.
M20		Pneumatic drive	1	Festo
Q20		5/2 directional control valve, bistable	1	Festo
		Silencer, if necessary	2	Festo
R20	H-...-B; H-QS-...; HA-...-QS-...; HB-...-QS-...	Check valve	1	Festo
S1		Acknowledge push button	1	
S2		Safety commanding device, e.g. emergency stop switch	1	
S20		Switch functional control	1	
T1		Safety switching device	1	

1.1.3 Description

Application	Double acting pneumatic drive
Triggering event	Safety request, e.g. by emergency stop switch, safety gate
Reaction (Safety Sub-function)	<p>Safe Direction (SDI) at stopping, category 1, PL c</p> <p>Subsystem valves</p>  <p>Prevention of unexpected start-up, category 1, PL c</p> <p>Subsystem valves</p> 
Safe state	<p>One chamber of the pneumatic drive is supplied with compressed air and the other chamber is exhausted. This can cause a movement in the direction in which there is no additional risk. The pneumatic drive will come to a standstill in the corresponding end position and will be kept in this end position. It is assumed that this may be a safe condition.</p> <p>The circuit diagram shows the safe direction of movement during stopping as retraction. This circuit must be checked for its applicability to the specific application and adapted if necessary.</p> <p>If the operating pressure supply (G2) is exhausted, actuating the valve (Q20) can cause the pneumatic drive (M20) to be exhausted.</p> <p>Notes:</p> <ul style="list-style-type: none"> • The non-return valve (R20) is used to maintain the operating pressure when the compressed air supply is switched off or fails. After switching off or after failure of the operating pressure, a movement may occur due to the leakage which cannot be stopped. • The non-return valve (R20) is not necessary if there is no hazard after switching off or failure of the compressed air supply. • The use of a soft-start valve is recommended in order to be able to approach an end position in a controlled manner when the compressed air supply is switched on.
Function	<p>The safety requirement (S2):</p> <ol style="list-style-type: none"> 1. Interrupts the input circuit of the safety switching device (T1). 2. Switch off the safe outputs of the safety switching device (T1). 3. The solenoids of the valve (Q20) are no longer controlled. 4. The valve (Q20) switches to the normal position, exhausts one chamber and connects the compressed air supply to the other chamber of the pneumatic drive (M20). This controls the pneumatic drive (M20) in one direction and stops it in the end position.
Manual reset function	<ol style="list-style-type: none"> 1. After resetting the safety request (S2), e.g. by mechanically unlocking the emergency stop switch or closing the safety guard, the start or restart can be made possible by pressing the acknowledge push button (S1). 2. The safety switching device (T1) can then allow the solenoid of the valve (Q20) to be controlled so that normal operation is possible.

1.1.4 Safety Considerations

Input	Safety considerations must be carried out in accordance with the selected safety commanding device (S2).
Logic	Safety considerations must be carried out in accordance with the selected safety switching device (T1).
Output	The valve (Q20, R20) are well-tried components according to EN ISO 13849-1 and the relevant basic and well-tried safety principles have been observed. B10 value required for the calculation of the $MTTF_D$ must be available.

2 Literature

- [1] VDMA 24584:2016-08 - Safety functions of regulated and unregulated (fluid) mechanical systems (German edition)
- [2] DIN EN ISO 13849-1:2016-06 - Safety of machinery - Safety-related parts of control systems - Part 1: General principles for design (ISO 13849-1:2015); German version EN ISO 13849-1:2015