


### **CMMT-AS Parallel Axis Synchronous Position Relative 1**

When 2 physical axis of are mechanically connected together by the load or other means (examples: gantry system X/X' coupled by a Y-Axis or 2 x ESBF rods attached), then it is necessary to synchronise these axis with an electronic alignment (Master to Slave).

CMMT-AS-xx

This application note discusses the required settings to control the 2 x parallel linear axis in Synchronous Position Relative1 mode using CMMT-AS-xx controllers.



Title .....CMMT-AS Parallel Axis Synchronous Position Relative 1  
Version ..... 1.20  
Document no. .... 100343  
Original .....en  
Author .....Festo  
Last saved ..... 02.11.2022

## Copyright Notice

This documentation is the intellectual property of Festo SE & Co. KG, which also has the exclusive copyright. Any modification of the content, duplication or reprinting of this documentation as well as distribution to third parties can only be made with the express consent of Festo SE & Co. KG.

Festo SE & Co KG reserves the right to make modifications to this document in whole or in part. All brand and product names are trademarks or registered trademarks of their respective owners.

## Legal Notice

Hardware, software, operating systems and drivers may only be used for the applications described and only in conjunction with components recommended by Festo SE & Co. KG.

Festo SE & Co. KG does not accept any liability for damages arising from the use of any incorrect or incomplete information contained in this documentation or any information missing therefrom.

Defects resulting from the improper handling of devices and modules are excluded from the warranty.

The data and information specified in this document should not be used for the implementation of safety functions relating to the protection of personnel and machinery.

No liability is accepted for claims for damages arising from a failure or functional defect. In other respects, the regulations with regard to liability from the terms and conditions of delivery, payment and use of software of Festo SE & Co. KG, which can be found at [www.festo.com](http://www.festo.com) and can be supplied on request, shall apply.

All data contained in this document do not represent guaranteed specifications, particularly with regard to functionality, condition or quality, in the legal sense.

The information in this document serves only as basic information for the implementation of a specific, hypothetical application and is in no way intended as a substitute for the operating instructions of the respective manufacturers and the design and testing of the respective application by the user.

The operating instructions for Festo products can be found at [www.festo.com](http://www.festo.com).

Users of this document (application note) must verify that all functions described here also work correctly in the application. By reading this document and adhering to the specifications contained therein, users are also solely responsible for their own application.

# Table of contents

<b>1</b>	<b>Components/Software/Firmware used .....</b>	<b>5</b>
1.1	Recommended Manuals .....	6
1.2	Attachments/Dependencies .....	7
1.3	Network Topology of the tested systems .....	8
<b>2</b>	<b>Overview of Required Steps .....</b>	<b>9</b>
<b>3</b>	<b>Project Configuration.....</b>	<b>11</b>
3.1	Create New Project .....	11
<b>4</b>	<b>Master Axis General Setup .....</b>	<b>12</b>
4.1	First setup - Start Wizard .....	12
4.2	First setup - Drive Configuration .....	12
4.3	First setup - Device Settings .....	13
4.4	First setup - Application Data .....	15
4.5	First setup - Hardware switches .....	16
4.6	First setup - Homing Method .....	16
4.7	First setup - Software Limits .....	17
4.8	Correct Parameters.....	18
4.9	Setup Complete.....	19
<b>5</b>	<b>Master Axis Changes Required for Parallel Axis.....</b>	<b>20</b>
5.1	Encoder Interface .....	20
5.2	Record Table .....	22
<b>6</b>	<b>Slave Axis General Setup .....</b>	<b>23</b>
6.1	First setup - Start Wizard .....	23
6.2	First setup - Drive Configuration .....	24
6.3	First setup - Device Settings .....	25
6.4	First setup - Application Data .....	25
6.5	First setup - Hardware switches .....	26
6.6	First setup - Homing Method .....	26
6.7	First setup - Software Limits .....	27
6.8	Correct Parameters.....	28
6.9	Setup Complete.....	29
<b>7</b>	<b>Slave Axis Changes Required for Parallel Axis .....</b>	<b>30</b>
7.1	Encoder Interface .....	30
7.2	Record Table .....	31
7.3	Parameter List .....	32
7.4	Master/Slave.....	33
<b>8</b>	<b>Commissioning Steps .....</b>	<b>34</b>
8.1	Download both axis configurations .....	34
8.2	Store both axis configurations .....	34

8.3	Master and Slave X10 physical connection .....	35
8.4	Master and Slave cycle power .....	37
8.5	Master axis Acknowledge Faults .....	37
8.6	Slave axis Acknowledge Faults .....	37
8.7	Master Slave Mechanical Alignment.....	39
8.8	Master Enable Plug-in PLC Control and Powerstage .....	38
8.9	Slave a Enable Plug-in PLC Control and Powerstage.....	38
8.10	Master Homing .....	39
8.11	Slave Homing .....	40
8.12	Slave Record Table .....	41
8.13	Slave Synchronisation is now Complete .....	41
<b>9</b>	<b>Error Recovery .....</b>	<b>42</b>
<b>10</b>	<b>General Design Considerations .....</b>	<b>43</b>



# 1 Components/Software/Firmware used

Type/ Name	Version Soft- ware/ Firmware	Description
CMMT-AS-C4-3A-MP-S1 (Master)	V31.0.7.10	Firmware
CMMT-AS-C2-3A-EP-S1 (Slave)	V22.0.3.88	Firmware
Festo Automation Suite	V2.4.0.442	Software
CMMT-AS Plug-in	V2.4.1.23	Software
RSLogix 5000/ Logix Designer 5000	V20.04	Rockwell Programming Software
1769-L30ERM	V20.019	CompactLogix 5370 Controller

Table 1.1: 1 Components/Software used

## 1.1 Recommended Manuals



### A) CMMT-AS Software/Function/Fieldbus/Device Profile Manual

	<b>Manual CMMT-AS-SW-EN</b> Servo drive - Bus interface - Function - Device profile - Software	 <b>Manual</b> → File and language versions
---	---	---

Reference:

[https://www.festo.com/net/en\\_ca/SupportPortal/Downloads/648237/725657/CMMT-AS-SW\\_manual\\_2022-04i\\_8173126g1.pdf](https://www.festo.com/net/en_ca/SupportPortal/Downloads/648237/725657/CMMT-AS-SW_manual_2022-04i_8173126g1.pdf)

### B) CMMT-AS Wiring & Installation Manual

	<b>Description CMMT-AS-C2_4-3A-EN</b> Servo drive - Installation - Assembly - Safety function	 <b>Description</b> → File and language versions
---	--	--

Reference:

[https://www.festo.com/net/en\\_ca/SupportPortal/Downloads/648246/720730/CMMT-AS-C2\\_4-3A-manual\\_2022-03e\\_8173941g1.pdf](https://www.festo.com/net/en_ca/SupportPortal/Downloads/648246/720730/CMMT-AS-C2_4-3A-manual_2022-03e_8173941g1.pdf)



### C) CMMT-AS Wiring & Installation Safety Function Manual

	<b>Description CMMT-AS-S1-EN</b> Safety function - SBC - SS1 - STO	 <b>Description</b> → File and language versions
--	---	--

Reference:

[https://www.festo.com/net/en\\_ca/SupportPortal/Downloads/648247/720882/CMMT-AS-S1\\_manual\\_2022-03e\\_8173923g1.pdf](https://www.festo.com/net/en_ca/SupportPortal/Downloads/648247/720882/CMMT-AS-S1_manual_2022-03e_8173923g1.pdf)

### D) CMMT-AS Short Documentation/Quick Guide Manual

	<b>Short documentation CMMT-AS-3A-QUICKGUIDE-EN</b> Servo drive - Quick guide	 <b>Short documentation</b> → File and language versions
---	--	--

Reference:


[https://www.festo.com/net/en\\_gb\\_gb/SupportPortal/Downloads/629760/696705/CMMT-AS-3A-QUICKGUIDE\\_2019-05\\_8100291g1.pdf](https://www.festo.com/net/en_gb_gb/SupportPortal/Downloads/629760/696705/CMMT-AS-3A-QUICKGUIDE_2019-05_8100291g1.pdf)

## **1.2 Attachments/Dependencies**

None

### 1.3 Network Topology of the tested systems

Please refer to the picture below and make sure all wires are correctly placed and connected. The user manuals (reference provided in section 1.1 Recommended Manuals) will need to be referenced for other wiring not shown here.





## 2 Overview of Required Steps

1. Both the **Master and Slave axis must use a multi-turn absolute encoder.**
2. Mechanically align the two axis
3. Reference both axis so they have the same absolute position value (perfect electronic alignment)
4. After each power off (examples: after activation of STO or SBC or the CTRL-EN removed), the electronic alignment of the two axes is required. This is accomplished using the PLC code and Fieldbus to read the Master axis position and then execute the Slave axis to the same absolute position.
5. After electronic alignment is completed, then the Slave axis executes an Up Synchronisation, Relative 1 command and the axis are then in Synchronisation
6. It is up to the PLC to monitor the status and positions of both Master and Slave and react if errors or position errors are observed.

Up synchronisation, "synchronous position, relative 1" mode




Fig. 116: Synchronous position, relative (example)




Fig. 117: Up synchronisation, "synchronous position, relative 1" mode

Caption	
1	"Synchronous position, relative 1" mode is executed.
2	Start Sync Pos (start of up synchronisation)
3	Master Sync Pos (target at which up synchronisation must be completed.)
4	End Sync Pos (start of down synchronisation)

Tab. 640: Legend for up synchronisation, "Synchronous position, relative 1" mode

At position (1), the Sync mode is executed, the virtual master position is set to 0 and the current slave position (5) is detected. If the virtual master axis reaches the position (2) "Start Sync Pos", it is up synchronised to the sum of virtual master position and recorded slave position.

On completion of up synchronisation the slave is relative to the position at which the sync mode was executed. If synchronisation is completed, the slave reports the status "Slave synchronous". Synchronisation must be completed before "Master Sync Pos".


Between positions (3) and (4), the slave reports the status "Master Sync Pos" reached. If the virtual master axis exceeds the position (4) "End Sync Pos", the down synchronisation is initiated.

Example: the slave is at 200 mm and the master position at 50 mm, Master Sync Pos = 100 mm and the sync mode is started (virtual master position = 0). After reaching the position "Master Sync Pos", the master position is at 150 mm, the slave at the absolute position of 300 mm and moves synchronously with the virtual master position.


### 3 Project Configuration

#### 3.1 Create New Project

Start a new project




Add the 2 x CMMT-xx-xx controllers you have purchased for the application and name them accordingly




4 Master Axis General Setup

4.1 First setup - Start Wizard



4.2 First setup - Drive Configuration

This application considers the maximum range of 175 mm



### 4.3 First setup - Device Settings

Consider the application Supply Voltage and modify from default if needed

AUTOMATION SUITE

CMMT\_MP\_DC\_1\_v2.4.1....\*

CMMTAS\_MP\_Master

FESTO

First setup

Drive Configurati...

Device Settings

Fieldbus

Application Data

Hardware Switches

Homing Method

Software Limits

Enable Servo Drive

Activation via

I/O and fieldbus (0)

Supply Voltage

Mains voltage

120.00

V

DC Link

Warning

If the DC circuit is linked to that of another drive, the rapid discharge function needs to be deactivated in order to protect the device.

Rapid discharge

☒ Active

Back

Next

Finish

CMMT\_MP\_DC\_1\_v2.4.1.28\_EthIP\_MasterSlave\_Linear


CMMTAS\_MP\_Master (Plug-in: CMMT-AS Plug-in V2.4.1.23)

Operator (30)

Festo Automation Suite V2.4.0.442

4.4 First setup - Fieldbus

Select EtherNet/IP – Modbus (3) for the RTE ethernet ports and Telegram 111, then modify the IP Address



#### 4.5 First setup - Application Data

Consider the application design

AUTOMATION SUITE  
CMMT\_MP\_DC\_1\_v2.4.1....\*

CMMTAS\_MP\_Master x

FESTO

<

First setup

Drive Configurati...

Device Settings

Fieldbus

Application Data

Hardware Switches

Homing Method

Software Limits

Application Data

Axis mass0.37 kg

Application mass kg

Total mass2.47 kg

Rotation Polarity

Please select the mounting position of the motor (viewed from top):

☒ Invert rotation polarity

Back

Next

Finish

CMMT\_MP\_DC\_1\_v2.4.1.28\_EthIP\_MasterSlave\_Linear | CMMTAS\_MP\_Master (Plug-in: CMMT-AS Plug-in V2.4.1.23)

Operator (30)

Festo Automation Suite V2.4.0.44

## 4.6 First setup - Hardware switches

The screenshot shows the 'First setup' screen for 'Hardware Switches' in the FESTO Automation Suite. The top bar includes the 'AUTOMATION SUITE' logo, a search icon, and a window title 'CMMTAS\_MP\_Master'. The main navigation bar has icons for 'Drive Configurati...', 'Device Settings', 'Fieldbus', 'Application Data', 'Hardware Switches' (highlighted with a red box), 'Homing Method', and 'Software Limits'. The 'Hardware Switches' section contains two dropdown menus: 'Reference switch configuration' set to 'Deactivated (0)' and 'Limit switches configuration' set to 'Not used (1)', both highlighted with red boxes. At the bottom, there are 'Back', 'Next', and 'Finish' buttons. The status bar at the very bottom shows 'CMMT\_MP\_DC\_1\_v2.4.1.28\_EthIP\_MasterSlave\_Linear', 'CMMTAS\_MP\_Master (Plug-in: CMMT-AS Plug-in V2.4.1.23)', 'Operator (30)', and 'Festo Automation Suite V2.4.0.442'.

## 4.7 First setup - Homing Method


The simplest Homing method is current position (37) with no movement. This is because after the mechanical alignment, this allows the axis to reference and store the offset in the existing position **without any movement**. In this example, the Negative stop was used to have the Master offset from mechanical end of stroke, then the Slave Axis would be aligned to its physical zero later.

The screenshot shows the 'First setup' screen for 'Homing Method' in the FESTO Automation Suite. The top bar is identical to the previous screen. The main navigation bar highlights 'Homing Method' with a red box. The 'Homing Method' section features a 'Method' dropdown set to 'Negative stop (-17)', which is highlighted with a red box and includes a diagram of a scale with a zero point. Below this, the 'Nominal current limit value scaling factor' is set to '0.30'. The 'Move to axis zero point after homing' checkbox is checked and labeled 'Active', also highlighted with a red box. 'Back', 'Next', and 'Finish' buttons are at the bottom. The status bar at the bottom is identical to the previous screen.





4.8 First setup - Software Limits

The Software Limits should be observed however, this depends on your application. A software limit larger than that of -3.00mm may be required to avoid mechanical limitations with the Slave alignment.



4.9 Correct Parameters

If you find orange adorners/indicators, these are warning to indicate unfavorable or inconsistent values and these may need to be modified. It is recommended to use the “Correct Parameters” function to modify the parameters with recommended values as shown below.



## 4.10 Setup Complete

Master axis general configuration is now complete.

**AUTOMATION SUITE**  
CMMT\_MP\_DC\_1\_v2.4.1...\*

**CMMTAS\_MP\_Master**

**PARAMETERIZATION** CONTROL DIAGNOSIS

**CMMTAS\_MP\_Master**  
CMMT-AS-C4-3A-MP-S1  
Path: 192.168.1.223  
Disconnected

**Connect**

Plug-in PLC Control Enabled Disabled Powerstage Stop Acknowledge All Store on Device Load Factory Settings Reinitialize Restart Device

**Parameter pages** < Drive Configuration > Further Information

**Drive Configuration**

Please Select the Components of Your Drive System

	<b>CMMT-AS-C4-3A-MP-S1</b> 8143164 Licenses	<b>Maximum Current</b> 12.00 A	<b>Intermediate Circuit Voltage</b> 320.00 V	<b>Supply Volt</b> 120.00 V	
	<b>EMMS-AS-S5-S-TM</b> 550111	<b>Type</b> Servo motor (2)	<b>Holding Brake</b> No	<b>Encoder Protocol</b> EnDat 2.1 (2)	<b>Encoder Type</b> Multi turn (2)
	<b>EGC-70-175-TB-KF-0H-GK</b> 556813	<b>Axis Size</b> 70	<b>Feed Constant</b> 78.00 mm/r	<b>Working Stroke</b> 175.00 mm	
	<b>EAMM-A-L38-60G</b> 557978	<b>Type</b> Axial	<b>Gear Ratio</b> 1:1		
	<b>EMGA-60-P-GS-SAS-S5</b> 552189	<b>Gear Ratio</b> 5:1			
	No gear configured				
	No gear configured				

**Gear Ratio (Total): 5:1**

**Further Information**

CMMT-AS-C4-3A-MP-S1

Overview

Device Details

Support

CMMT\_MP\_DC\_1 v2.4.1.28 FnhIP MasterSlave Linear | CMMTAS\_MP\_Master (Plug-in: CMMT-AS Plug-in V2.4.1.23) Operator (30) Festo Automation Suite V2.4.0.4

## 5 Master Axis Changes Required for Parallel Axis

### 5.1 Encoder Interface

The screenshot displays the 'Encoder Interface' configuration page in the CMMTAS\_MP\_Master software. The left sidebar shows a tree view with 'Encoder Interface' selected. The main configuration area is divided into 'Feed Constant' and a table comparing 'DEFAULT' and 'CHANGES' for various parameters. The 'CHANGES' column has a red box around the 'Increments per revolution' value of 16383. A blue callout bubble points to the '78.00 mm/r' value with the text 'Note for use in Slave'.

	DEFAULT	CHANGES	
Selection of sync mode	Master (0)	Master (0)	P0.5812
Encoder emulation source	Encoder 1 (0)	Encoder 1 (0)	P1.581
Activate encoder emulation output	<input checked="" type="checkbox"/> Active	<input checked="" type="checkbox"/> Active	P1.583
Deactivate encoder emulation during homing	<input checked="" type="checkbox"/> Active	<input checked="" type="checkbox"/> Active	P1.8421
Increments per revolution	4096	16383	P1.586
Offset position	0.00 mm	0.00 mm	P1.586846
Activation counting direction reversal	<input type="checkbox"/> Active	<input type="checkbox"/> Active	P1.586847

#### P1.581 Encoder Emulation Source

Encoder 1 (0) refers to the Primary encoder at connection X2

Encoder 2 (1) refers to the Secondary encoder at connection X3

Setpoint position (2), less noise is observed on the Slave, however the slave doesn't follow when Master is disabled because no setpoint is changed.

#### P1.583 Activate Encoder Emulation

Encoder 1 (0) refers to the X10 encoder connection.

When this has been chosen, regardless of the presence of the cable connection, the top LED is active solid green.

Turning this on allows Encoder Emulation by the Master.

#### P1.8421.0.0 Deactivate Encoder Emulation During Homing

The state of this is irrelevant because the Master and Slave axis both have Multi-Turn Absolute Encoders and once homed are not homed gain.

#### P1.586 Increments per revolution


16383 Increments per revolution allows for better tuning when in Synchronisation (The greater the selected value the lower the resulting noise on the connected slave axes).



#### Caution

- The same resolution per revolution should be set in the Master and slave drive.
- DO NOT USE THE VALUE "16384" (only allowed in Master on older software versions)  
See note for Slave axis parameter P0.10040.2.0 Increments per revolution


When it is necessary to adjust the direction of rotation in an application, the Px.1171 direction reversal should be used in the slave drive.



The screenshot shows the FESTO CMMTAS\_MP\_Master software interface. The top bar displays the title "AUTOMATION SUITE CMMTAS\_MP\_Master" and a red box around the window title "CMMTAS\_MP\_Master". The left sidebar contains a tree view with "Record Table" highlighted in a red box. The main area displays a "Record table" with columns for Record type, Type, Target position, Profile velocity, Acceleration, Deceleration, Jerk, and End velocity. A blue arrow points from the "Record Table" in the sidebar to the table. A red box highlights the "Click Here" button in the bottom right corner of the table.

## 6 Slave Axis General Setup

### 6.1 First setup - Start Wizard



## 6.2 First setup - Drive Configuration

Configure the hardware selected for the application.

**NOTE: Working Stroke** -> In this example, the Master and Slave physical axis stroke are both 175mm, however, it is recommended to configure the value of the Slave Working Stroke slightly larger (200mm which provides a physical 15mm buffer). This concept is to avoid the Slave from entering an software overtravel status and losing the synchronisation at any time.



### Caution

The Slave axis should not be able to encounter a software or hardware limit otherwise it can lose synchronisation which could cause an issue depending on the monitoring of the higher order PLC (Programmable Logic Controller).

**First setup**

Please Select the Components of Your Drive System

	<b>CMMT-AS-C2-3A-EP-S1</b> 5340824 Licenses	<b>Maximum Current</b> 6.00 A	<b>Intermediate Circuit Voltage</b> 320.00 V	<b>Supply Voltage</b> 120.00 V			
	<b>EMMT-AS-60-S-LS-RMB</b> 5242199	<b>Type</b> Servo motor (2)	<b>Holding Brake</b> Yes	<b>Encoder Protocol</b> EnDat 2.2 (5)	<b>Encoder Type</b> Multi turn (2)	<b>Voltage</b> 325.00 V	
	<b>EGC-70-200-TB-KF-0H-GK</b> 556813	<b>Axis Size</b> 70	<b>Feed Constant</b> 78.00 mm/r	<b>Working Stroke</b> 200.00 mm			
	<b>EAMM-A-L38-60H</b> 1456610	<b>Type</b> Axial	<b>Gear Ratio</b> 1:1				
	<b>EMGA-60-P-G5-EAS-60</b> 2297687	<b>Gear Ratio</b> 5:1					

Back Next Finish

CMMT\_MP\_DC\_1\_v2.4.1.28\_EthIP\_MasterSlave\_Linear | CMMTAS-EP\_Slave (Plug-in: CMMT-AS Plug-in V2.4.1.23) | Operator (30) | Festo Automation Suite V2.4.0.442



### 6.3 First setup - Device Settings

Consider the IP Address and Supply Voltage and be certain that Telegram 111 is selected

AUTOMATION SUITE  
CMMT\_MP\_DC\_1\_v2.4.1....

CMMTAS-EP\_Slave

First setup

Drive Configurati...

Device Settings

Application Data

Hardware Switches

Homing Method

Software Limits

**Enable Servo Drive**

Activation viaI/O and fieldbus (0)

**Supply Voltage**

Mains voltage120.00 V

**DC Link**

Warning  
If the DC circuit is linked to that of another drive, the rapid discharge function needs to be deactivated in order to protect the device.

Rapid discharge☒ Active

**Configuration**

Telegram selectionTelegram (111)

Activate DHCP☐ Active

IP address192 . 168 . 1 . 185

Subnet mask255 . 255 . 255 . 0

Gateway address0 . 0 . 0 . 0

BackNextFinish

CMMT\_MP\_DC\_1\_v2.4.1.28\_EthIP\_MasterSlave\_Linear | CMMTAS-EP\_Slave (Plug-In: CMMT-AS Plug-in V2.4.1.23)Operator (30)Festo Automation Suite V2.4.0.44d

## 6.4 First setup - Application Data

Consider the application design.

The screenshot displays the 'Application Data' configuration screen within the Festo Automation Suite. The 'Application mass' input field is highlighted with a red box, showing a value of 0.10 kg. The 'Invert rotation polarity' checkbox is also highlighted with a red box and is currently unchecked. The interface includes a top navigation bar with icons for home, search, help, and a title bar with the text 'CMMTAS-EP\_Slave'. The bottom status bar shows the current project path and the operator's name.

Parameter	Value	Unit
Axis mass	0.37	kg
Application mass	0.10	kg
Total mass	0.47	kg

## 6.5 First setup - Hardware switches

**Hardware Switches**

Reference switch configuration: Deactivated (0)

Limit switches configuration: Not used (1)

Back Next Finish

CMMT\_MP\_DC\_1\_v2.4.1.28\_EthIP\_MasterSlave\_Linear | CMMTAS-EP\_Slave (Plug-in: CMMT-AS Plug-in V2.4.1.23) | Operator (30) | Festo Automation Suite V2.4.0.442

## 6.6 First setup - Homing Method

The simplest Homing method is current position (37) and the Move to Axis zero point after homing should be unchecked/disabled. These settings allow the axis to reference and store the offset in the current position **without any movement**.

**Homing Method**

Method: Current position (37)

Nominal current limit value scaling factor: 0.30


Move to axis zero point after homing: ☐ Active

Back Next Finish

CMMT\_MP\_DC\_1\_v2.4.1.28\_EthIP\_MasterSlave\_Linear | CMMTAS-EP\_Slave (Plug-in: CMMT-AS Plug-in V2.4.1.23) | Operator (30) | Festo Automation Suite V2.4.0.442


6.7 First setup - Software Limits

The Axis zero point offset should be configured as 0.00mm because during the execution of reference/homing, The Master position will already be at 0.00mm and the slave needs to match this position. The Software Limits should be active (default) in this step. The default values for negative/positive position limits should be adequate because the values of the slave should be beyond the physical stroke at either end of the axis (this was discussed earlier in section “First setup - Drive Configuration”).



## 6.8 Correct Parameters

If you find orange adorners/indicators (example shown here), these are warning to indicate unfavorable or inconsistent values and these may need to be modified. It is recommended to use the “Correct Parameters” function to modify the parameters with recommended values as shown below.



The screenshot shows the 'Correct parameters' dialog box in the FESTO AUTOMATION SUITE. The dialog box displays a table of parameters with their actual values and recommended values. A red box labeled 'Click Here' points to the 'Click Here' button in the top left corner of the dialog box.

ID	Name	Actual value	Recommended value	Unit
<input checked="" type="checkbox"/> P1.850.0.0	Lower limit value velocity (clos...	-16666670000000000000000000000000.00	-16.66667	m/s
<input checked="" type="checkbox"/> P1.851.0.0	Upper limit value velocity (clos...	16666670000000000000000000000000.00	16.66667	m/s
<input checked="" type="checkbox"/> P1.852.0.0	Lower limit value torque (close...	-10000000000000000000000000000000.00	-0.5472	Nm
<input checked="" type="checkbox"/> P1.853.0.0	Upper limit value torque (close...	10000000000000000000000000000000.00	0.5472	Nm
<input checked="" type="checkbox"/> P1.854.0.0	Lower limit value active current...	-10000000000000000000000000000000.00	-3.20	Arms
<input checked="" type="checkbox"/> P1.855.0.0	Upper limit value active current...	10000000000000000000000000000000.00	3.20	Arms
<input checked="" type="checkbox"/> P1.856.0.0	Limit value total current (closed...	10000000000000000000000000000000.00	3.20	Arms
<input checked="" type="checkbox"/> P1.1305.0.0	Upper limit value acceleration li...	56713670000000000000000000000000.00	100.00	m/s <sup>2</sup>
<input checked="" type="checkbox"/> P1.1306.0.0	Upper limit value deceleration li...	56713670000000000000000000000000.00	100.00	m/s <sup>2</sup>
<input checked="" type="checkbox"/> P1.1310.0.0	Limit value velocity limit negati...	-56713670000000000000000000000000.00	-16.66667	m/s
<input checked="" type="checkbox"/> P1.103113.0.0	Torque positive limit value	1.00	0.5472	Nm
<input checked="" type="checkbox"/> P1.103113.1.0	Torque positive limit value	1.00	0.5472	Nm
<input checked="" type="checkbox"/> P1.103115.0.0	Torque negative limit value	-1.00	-0.5472	Nm
<input checked="" type="checkbox"/> P1.103115.1.0	Torque negative limit value	-1.00	-0.5472	Nm

14/14

Click Here

Apply Cancel

## 6.9 Setup Complete

Slave axis general configuration is now complete.

**AUTOMATION SUITE**  
CMMT\_MP\_DC\_1\_v2.4.1....\*

**CMMTAS-EP\_Slave**

**PARAMETERIZATION** CONTROL DIAGNOSIS

**CMMTAS-EP Slave**  
CMMT-AS-C2-3A-EP-S1  
Path: 192.168.1.184  
Disconnected

**Connect**

Plug-in PLC Control  
Enabled Disabled Powerstage  
Stop  
Acknowledge All  
Store on Device  
Load Factory Settings  
Reinitialize  
Restart Device

Parameter pages < Drive Configuration > Further Information

**Drive Configuration**

Please Select the Components of Your Drive System

	<b>CMMT-AS-C2-3A-EP-S1</b> 5340824 Licenses	<b>Maximum Current</b> 6.00 A	<b>Intermediate Circuit Voltage</b> 320.00 V	<b>Supply Voltage</b> 120.00 V		
	<b>EMMT-AS-60-S-LS-RMB</b> 5242199	<b>Type</b> Servo motor (2)	<b>Holding Brake</b> Yes	<b>Encoder Protocol</b> EnDat 2.2 (5)	<b>Encoder Type</b> Multi turn (2) <b>Voltage</b> 325.00 V	
	<b>EGC-70-200-TB-KF-0H-GK</b> 556813	<b>Axis Size</b> 70	<b>Feed Constant</b> 78.00 mm/r	<b>Working Stroke</b> 200.00 mm		
	<b>EAMM-A-L3B-60H</b> 1456610	<b>Type</b> Axial	<b>Gear Ratio</b> 1:1			
	<b>EMGA-60-P-GS-EAS-60</b> 2297687	<b>Gear Ratio</b> 5:1				

**Overview**

Device Details

Support

CMMT-AS-C2-3A-EP-S1

## 7 Slave Axis Changes Required for Parallel Axis

### 7.1 Encoder Interface

164

The feed constant for Encoder interface 3 [X10] must match the Master feed constant.  
Here we tell the controller how to convert the increments per revolution after the gear into position units.

P0.5812 Selection of Sync Mode

Here we configure as Slave(1) for obvious reasons.

P0.11616.2.0 Encoder selection

The Master X10 port emulates an Incremental Encoder so this is selected here.



#### Caution

If actual values are transmitted to the slave as position signals (P1.581 Encoder Emulation Source = Encoder 1 or Encoder 2), increased noise may occur due to the torque feed forward control in the synchronous phase. The torque feed forward control is switched off by setting parameter Px.968 to 0.

P0.10040.2.0 Increments per revolution

16383 Increments per revolution allows for better tuning when in Synchronisation.




#### Caution


- The same resolution per revolution should be set in the Master and slave drive!
- DO NOT USE THE VALUE "16384" for parameter P0.10040.2.0 Increments per revolution. This will result with an exception in the firmware when re-initializing the drive (div/0) and the hardware will need to be replaced (cannot be fixed onsite). The firmware release V19.0.4.72 is supposed to address this issue.

7.2 Record Table

The Record Table needs to have the shown Gear In **Synchronous Position Relative 1** mode added. This will be used to place the Slave axis in synchronisation when desired.



7.3 Parameter List



P1.101116.0.0 Hardware Limits Disabled  
This option should be disabled to prevent undesirable behavior while in sync.




**Caution**  
If the Slave axis is in synchronisation to the Master and a Hardware limit is encountered, the slave will be inhibited by the limit and will NOT follow the Master.



7.4 Master/Slave

The Slave axis Master/Slave page needs to be configured based on the Device Configuration Axis Working Stroke. In this example, the Master and Slave physical axis stroke are both 175mm. The Slave is configured with 200mm (197mm Software Limit) to avoid loss of synchronisation. In order to correlate with the Slave Software limit and avoid losing synchronisation, the Master Sync Pos./End Sync Pos. and Master Stop Pos. are all configured with values greater than the Master axis physical stroke up to the unachievable Slave Stroke including the positive software limit.

The Encoder Interface 3 [X10] (3) needs to be selected so the Slave considers this as the Virtual Master Position.



## 8 Commissioning Steps

### 8.1 Download both axis configurations

The motor controller should have factory defaults, however, if a parameter synchronisation window appears, make certain to select “Write to Device”

The first screenshot shows the 'Parameter synchronisation' window for the CMMTAS\_MP\_Master. The table below lists the parameters to be synchronized:

ID	Name	Value in project	Unit	Value on device	Unit
P0.902.0.0	Device name	CMMTAS_MP_Master		CMMTAS_MP_Linear_M	
P0.12001.1.0	IP address	3232236000		0	
P0.12002.1.0	Subnet mask	4294967040		0	
P1.1813.0.1	Record table field 2	1650000000		1700000000	

The 'Write to Device' button is highlighted with a red box and a 'Click Here' label.

The second screenshot shows the 'Parameter synchronisation' window for the CMMTAS\_EP\_Slave. The table below lists the parameters to be synchronized:

ID	Name	Value in project	Unit	Value on device	Unit
P0.341.0.0	Trigger type	Data trigger (1)		Record immediately (0)	
P0.557.0.0	Trace delay	1715		2002	
P0.558.0.0	Recording length	2287		8000	
P0.559.0.0	Down sampling factor	14		8	
P0.902.0.0	Device name	CMMTAS_EP_Slave		CMMTAS_EP_185_Linear	
P0.5812.0.0	Selection of sync mode	Slave (1)		Master (0)	

The 'Write to Device' button is highlighted with a red box and a 'Click Here' label.

### 8.2 Store both axis configurations

The first screenshot shows the 'Store on Device' button highlighted with a red box and a 'Click Here' label for the CMMTAS\_MP\_Master. The status bar indicates 'Connected'.

The second screenshot shows the 'Store on Device' button highlighted with a red box and a 'Click Here' label for the CMMTAS\_EP\_Slave. The status bar indicates 'Error'.


### 8.3 Master and Slave X10 physical connection

Confirm X10 connectors on the Master and Slave are physically connected



#### Caution

- There is no physical wire break detection on the Slave and so monitoring position error in the PLC (Programmable Logic Controller) is required for error recovery.




## 8.4 Hardware Control Enable Cross-Wiring

As mentioned in the **Caution** note above, the X10 Ethernet cable has no physical wire break detection in the Master or Slave controller software.

- In applications with rigid mechanical coupling, an offset between master and slave can lead to distortion, even mechanical destruction of the system. To avoid such risk, a reliable solution must be deployed.
- In the event of an error of the Slave, the Master should stop as soon as possible, in the best case with the delay dynamics of the Slave. Such a shutdown via the higher-level controller is usually subject to the update time of the fieldbus system and the cycle time of the controller. Therefore, hardware control enable cross-wiring is recommended in this case. The Master can be enabled by a ready signal, physically via the potential-free contact RDY-C1/C2 of the Slave. If the Slave now goes into error state, the CNTRL-EN of the Master will be removed, which leads to a stop ramp and following stop. The Master can also be enabled again only if there is no more error in the Slave. If the hardware cross-wiring shown here conflicts with the safety circuit of the Master (CTRL-EN), the Master can also be disabled in the event of an error via a digital input and using the event table.
- In case of error to the Master, the Slave still will follow the Master's position. It must be ensured that Slave drive can follow the dynamics of the Master's stop ramp. If it cannot be guaranteed, cross-wiring is also recommended for the Slave.

### 8.4.1 Wiring IO (Inputs/Outputs) Connector Function




### 8.4.2 Wiring Example

The wiring shown here is very simple and will react very fast to an error on the Slave.



### 8.4.3 Wiring Example With Bypass


If the user feels they will need to bypass this condition in certain circumstances, they could wire as follows:



## 8.5 Master and Slave cycle power


## 8.6 Master axis Acknowledge Faults

Go online with the CMMT Master axis and acknowledge any faults



## 8.7 Slave axis Acknowledge Faults

Go online with the CMMT Slave axis and acknowledge any faults



## 8.8 Master Enable Plug-in PLC Control and Powerstage

The screenshot shows the FESTO AUTOMATION SUITE interface. The top bar includes the 'AUTOMATION SUITE' title and tabs for 'PARAMETERIZATION', 'CONTROL', and 'DIAGNOSIS'. The 'DIAGNOSIS' tab is active. Below the tabs, there's a status bar for 'CMMTAS\_MP\_Master' (Connected) and 'CMMTAS-EP\_Slave'. The main area displays a 'Master Control Activation' dialog box with a yellow warning icon and the text: 'Taking over control via the plug-in will prevent a possibly connected PLC from controlling the drive. The system may stop.' The dialog box has 'Ok' and 'Cancel' buttons. Red boxes and arrows point to the 'Click Here' labels above the 'PLC Control' and 'Ok' buttons.

## 8.9 Slave Enable Plug-in PLC Control and Powerstage

The screenshot shows the FESTO AUTOMATION SUITE interface. The top bar includes the 'AUTOMATION SUITE' title and tabs for 'PARAMETERIZATION', 'CONTROL', and 'DIAGNOSIS'. The 'DIAGNOSIS' tab is active. Below the tabs, there's a status bar for 'CMMTAS\_MP\_Master' (Connected) and 'CMMTAS-EP\_Slave'. The main area displays a 'Master Control Activation' dialog box with a yellow warning icon and the text: 'Taking over control via the plug-in will prevent a possibly connected PLC from controlling the drive. The system may stop.' The dialog box has 'Ok' and 'Cancel' buttons. Red boxes and arrows point to the 'Click Here' labels above the 'PLC Control' and 'Ok' buttons.

## 8.10 Master Homing

As mentioned earlier, a different reference method may be required for the application.

## 8.11 Master Slave Mechanical Alignment



### Caution

- At this point, the mechanical alignment between the Master and Slave axis should be carried out. Depending on the application, this may include moving the Master and Slave axes before or after they are enabled.
- Only after the Master and Slave axes have been aligned perfectly should the Slave axis now be referenced/homed and have the encoder position offset stored at their existing aligned positions!

## 8.12 Slave Homing

The screenshot displays the FESTO Automation Suite interface for the 'CMMTAS-EP\_Slave' device. The 'CONTROL' tab is selected, and the 'Manual Movement' section is active. The 'Homing' process is shown with a diagram and a 'Click Here' button labeled '1'. Below the diagram, a message box asks 'Zero Point Offset Not Saved Yet' with a 'Click Here' button labeled '2'. A 'Saving zero point offset' progress bar is shown. Finally, a message box says 'Zero Offset Successfully Saved' with an 'Ok' button labeled '3'. The right sidebar shows various system status indicators like 'Active motion task', 'Referencing status', 'Setpoint Position', etc.



## 8.13 Slave Record Table

Execute the Record Table "Gear In Relative 1" move that was previously programmed

The first screenshot shows the FESTO Automation Suite interface with the 'Record Table' tab selected. A red box highlights the 'Record Table' tab, and another red box highlights the 'Click Here' button. The 'Record Table' shows a move for 'Gear In Relative 1' with a 'Record type' of 'Gear In/out (35)', 'Gear In Mode' of 'Synchronous Position Relative 1 (2)', 'Gear Out Mode' of 'Stop (0)', and an 'Offset' of '0.00 mm'. The 'Watch window' on the right shows the 'Active motion task' as 'Homings (3)' and 'Referencing status' as 'Drive referenced (200)'. The 'Setpoint Position' is '-3.0000001 mm', 'Position actual value (encoder 1)' is '-3.00 mm', 'Setpoint value velocity controller' is '0.00 m/s', and 'Velocity actual value (encoder 1)' is '-0.000022 m/s'.

The second screenshot shows the same interface, but the 'Active motion task' in the 'Watch window' is now 'Gear In/out (35)'. The 'Referencing status' is 'Drive referenced (200)', 'Setpoint Position' is '0.00 mm', 'Position actual value (encoder 1)' is '-2.9954701 mm', 'Setpoint value velocity controller' is '-0.0000647 m/s', and 'Velocity actual value (encoder 1)' is '-0.0001645 m/s'.

## 8.14 Slave Synchronisation is now Complete

The screenshot shows the FESTO Automation Suite interface with the 'Master/Slave' tab selected. The 'Position Diagram' shows a 'Gear In' phase with a 'Mode' of 'Synchronous v'. A red box highlights the 'Slave synchronisation completed (3)' status. The 'Watch window' on the right shows the 'Active motion task' as 'Gear In/out (35)' and 'Referencing status' as 'Drive referenced (200)'. The 'Setpoint Position' is '0.00 mm', 'Position actual value (encoder 1)' is '-2.995125 mm', 'Setpoint value velocity controller' is '0.00 m/s', 'Velocity actual value (encoder 1)' is '1.564719E-05 m/s', 'Active current setpoint' is '-0.008833 Arms', 'Actual active current' is '-0.008154 Arms', 'Actual value I<sup>2</sup> monitoring power output...' is '1.469902E-42 A/s', 'Torque setpoint' is '-0.0243057 Nm', 'Temperature power output stage' is '21.14712 °C', and 'Motor temperature' is '41.55001 °C'.

## 9 Error Recovery

After each power off (example: after activation of STO or SBC or the CTRL-EN removed), the electronic alignment of the two axes is required.

The re-synchronisation is accomplished as follows:

1. Synchronisation is lost and both axis have stopped due to some situation.
2. The exact electronic alignment of the two axis is "likely" un-coupled by a small amount of position error.
3. Synchronisation is now required
4. All safeties and any other cause for the loss of synchronisation are restored and both the parallel axis are enabled.
5. The PLC (Programmable Logic Controller) reads the current setpoint or actual position (depends which is suited best for the application) of the master.
6. The PLC requests the Slave axis move to the same absolute position read from the Master and confirms movement is completed.
7. The PLC requests the Slave axis to execute the Record Type "Gear In/Out" Mode Synchronous Position Relative 1 (2).

1	Gear In Relative 1	Record type	Gear In Mode	Gear Out Mode	Offset
		Gear In/out (35)	Synchronous Position Relative 1 (2)	Stop (0)	0.00 r

8. To confirm Gear In / Slave Up synchronisation Completed (3) the user can read the parameter P1.85607.0.0. When the slave axis is within the position and velocity tolerance window and synchronised with the virtual master position, the value will be three. This can be done with a MSG instruction or via Extended Process Data (EPD) as shown here by example.

**Value list of parameters Status (Px.85607)**

Value	Meaning
0	Inactive
1	Wait for Start Sync Pos
2	Slave synchronized to
3	Slave synchronisation completed
4	Master Sync Pos reached
5	Slave synchronizes down
6	Slave down synchronization completed
8	Gear Out Stop
100	Error

Tab. 635: Value list of [parameters Px.85607](#)

**Parameter: P1.85607.0.0**  
Description: Gear In Status  
Data Type: USINT (Unsigned)  
Access: RO

**Read Values:**

- 0 = Inactive / No Slave Synchronization
- 1 = Wait for Start Sync Pos
- 2 = Slave synchronized to
- 3 = Slave synchronisation completed
- 4 = Master Sync Pos reached
- 5 = Slave synchronizes down
- 6 = Slave down synchronization completed
- 8 = Gear Out Stop
- 100 = Error

**Gear In Status:**

- 0=Inactive
- 1=Wait Start SyncPos
- 2=Synchroized
- 3=Synch Complete
- 4=MasterSyncPos
- 5=SlaveSyncDown
- 6=SlaveSyncDown Done
- 8=Gear Out Stop
- 100=Error

**Slave 1 Synchronization Complete**

**Slave 1 Synchronization Complete**

**Slave 1 Synchronization Complete**


9. The electronic alignment of the two Parallel axis is now Completed
10. The PLC now goes back to monitoring the status and positions of both Master and Slave and reacts appropriately if errors or position errors are observed.

## 10 General Design Considerations



### Caution

After a loss of sync and then a re-sync recovery, it is normal that the Master Axis Position (Virtual Master Position) and Setpoint or Actual Position are a mismatch.



### Caution

Consider the possibility that the Emergency Stop electrical design which activates the STO or SBC or the CTRL-EN acts on the Master axis first so that the Slave axis can follow while the power stage is active. Then, after movement of the Master axis has halted (the slave following at all times with full power).