

S7 - Functional block to control SEC-AC-... via Profibus



FESTO

Description

Functional block
S7

Type
SEC-AC-...-PB-S7
(Version 3.8)



Description

538 513

en 0803 NH

[676 917]

Contents and general instructions

Original de
Layout Festo AG & Co KG., Abtl. KG-GD
Type setting DUCOM
Edition en 0803 NH
Designation P.BE-SEC-AC-PB-S7-EN
Order no. 538 513

© (Festo AG & Co KG., D-73726 Esslingen, Federal Republic of Germany 2003)

Internet: <http://www.festo.com>

E-Mail: service_international@festo.com

The reproduction, distribution and utilization of this document as well as the communication of its contents to others without expressed authorization is prohibited. Offenders will be held liable for the payment of damages. All rights reserved in the event of the grant of a patent, utility model or design.

Contents

Designated use	V
Fundamentals of programmed software	VI
Target group	VI
Important user instructions	VIII
1. Functional block "SEC-AC controller" V3.8	1-1
1.1 Module functions	1-3
1.1.1 Positioning (default operation mode)	1-3
1.1.2 Homing	1-3
1.1.3 Jogging	1-3
1.1.4 Torque regulation	1-3
1.1.5 Synchronous operation	1-3
2. Description of the functions with associated variables	2-1
2.1 General	2-3
2.1.1 LADDR_I / LADDR_O	2-3
2.1.2 EN_Drive / EN_ok	2-4
2.1.3 feed_constant	2-4
2.1.4 start_init	2-5
2.1.5 Position_actual_value / current_actual_value / digital_inputs	2-5
2.2 Homing	2-6
2.2. Methods of homing	2-7
2.3 Positioning	2-8
2.4 Jogging	2-10
2.5 Torque regulation	2-11
2.6 Synchronous operation	2-12
3. Adjust parameters	3-1
3.1 Bit mappings	3-3
3.1.1 Output byte "digital_inputs"	3-3
3.1.2 Output word "error"	3-3

Contents and general instructions

3.2	Notes on Profibus mode	3-4
3.3	Rotary axis	3-5
3.3.1	Procedure	3-5
3.3.2	Notes on application	3-6
3.4	Direct access to individual parameters in the controller	3-7
A.	Technical Appendix	A-1

Designated use

The functional block (FB) is used to control SEC-AC servo controllers in a SIMATIC-S7 controller via Profibus DP with integrated DP-Master module (e.g. CPU315-2DP)

The module allows the user to incorporate the various functions of the axis controller directly into their program.

Memory requirements for FB10 V3.8

Program memory	Storage memory	
functional block:	3316 byte	2826 bytes
Instance data module:	388 bytes	186 bytes

With multi-axis applications, the FB is accessed for each axis with a separate Instance-DB or Multi-instance. Further FBs and DBs are not required.

The simultaneous use of other FBs for controlling the same controller is not permitted.

The FB uses the System Functions SFC14 and SFC15 for consistent data transmission.

The module is incorporated into the user program and called there cyclically. A "start_init" marker is used for initialisation and parameterisation; this is deleted the first time it is called (e.g. via OB100).

Fundamentals of programmed software

Please note that it is not possible with the present state of the art of technology to create programmed software which functions faultlessly for and is compatible with all applications and combinations intended by the user.

The software is therefore to be used exclusively for the functions described in the programming manual and in the user instructions.

At the time of handing-over or availability of the software, the latter is in a form in which it functions under normal operating and application conditions.

Festo does not guarantee that the software is satisfactory for all applications and purposes of use intended by the user, or especially that it functions faultlessly and is compatible with other programs which are used. The responsibility for the correct selection and the consequences arising from use of the software in the environment selected by the user, as well as the therewith intended and achieved results lies with the user. The same applies to the printed material accompanying the software.

The use of the programmed software does not therefore exonerate the user from his obligations or from his responsibility for the observance and adherence to the machine and technical safety regulations as well as a comprehensive functional check.

Target group

This manual is aimed at technicians trained in control and automation technology, fitters etc. who

- are working for the first time with digital drive controllers
- are already familiar with digital drive controllers, but who are installing a digital drive controller like the SEC-AC for the first time.



Information:

Your contact partner for technical support with this product can be found on the Festo Internet pages under the address: www.festo.com [[country-specific homepage](#)]/Industrial Automation/<country column>



Information:

Supplementary software for your product (e.g. GSD Profibus file) can be found on the Festo Internet pages under the address: www.festo.com [Industrial Automation/Service & Support/Download Area].

Important user instructions

Danger categories

This manual contains instructions on the possible dangers which may occur if the product is not used correctly. These instructions are marked (Warning, Caution, etc), printed on a shaded background and marked additionally with a pictogram. A distinction is made between the following danger warnings:



Warning

... This means that failure to observe this instruction may result in serious personal injury or damage to property.



Caution

... This means that failure to observe this instruction may result in personal injury or damage to property.



Please note

... This means that failure to observe this instruction may result in damage to property.

The following pictogram marks passages in the text which describe activities with electrostatically sensitive components.



Electrostatically sensitive components may be damaged if they are not handled correctly.

Marking special information

The following pictograms mark passages in the text containing special information.

Pictograms



Information:

Recommendations, tips and references to other information sources.



The parameters thus marked affect the internal controller structure and must be used with caution.



Accessories:

Information on necessary or sensible accessories for the Festo product.

Text markings

- The bullet indicates activities which may be carried out in any order.
- 1. Figures denote activities which must be carried out in the numerical order specified.
- Hyphens indicate general activities.

Block overview

Chapter 1

1. Block overview

1.	Block overview	1-1
1.1	Block functions	1-3
1.1.1	Positioning (default operation mode)	1-3
1.1.2	Homing	1-3
1.1.3	Jogging	1-3
1.1.4	Torque regulation	1-3
1.1.5	Synchronous operation	1-3

1. Block overview

1.1 Block functions

1.1.1 Positioning (default operation mode)

Travelling to a defined position with a defined speed and acceleration/braking ramp. The position can be approached absolute or relative to the actual position. Profile movements are also possible through the specification of a final speed greater than zero with direct execution of the next positioning job.

1.1.2 Homing

Finding or specifying a reference position to reset the position counter. There are 15 different ways of doing this.

1.1.3 Jogging

Movement at variable speed in the selected direction, providing the relevant input is set.

1.1.4 Torque regulation

A defined force can be exerted using the drive without consideration of position and speed through the specification of a variable setpoint torque value.

1.1.5 Synchronous operation

Synchronising the drive to an external encoder signal provided via plug X10 as an additional setpoint position value.

This function can be selected in parallel to positioning mode.

1. Block overview

Input
variables

```
LADDR_I
LADDR_O
feed_constant
EN_drive
homing_method
home_offset
homing_speed_switch
homing_speed_zero
homing_acceleration
start_homing
absolut_0_relativ_1
change_set_immediately
target_position
profile_velocity
end_velocity
profile_acceleration
profile_deceleration
new_set_point
jogging_velocity
jogging_minus
jogging_plus
hold
fault_reset
enable_torque
target_torque
enable_sync
encoder_resolution
encoder_numerator
encoder_divisor
init_flag
```

Transit
variable

```
en_OK
following_error
position_ok
home_complete
set_point_acknowledge
digital_inputs
position_actual_value
current_actual_value
error
```

Output
variables

Fig. 1/1: SEC_control

1. Block overview

Description of the functions with associated variables

Chapter 2

2. Description of the functions with associated variables

Contents

2.	Description of the functions with associated variables	2-1
2.1	General	2-3
	2.1.1 LADDR_I / LADDR_O	2-3
	2.1.2 EN_Drive / EN_ok	2-4
	2.1.3 feed_constant	2-4
	2.1.4 start_init	2-5
	2.1.5 Position_actual_value / current_actual_value / digital_inputs	2-5
2.2	Homing	2-6
	2.2.1 Methods of homing	2-7
2.3	Positioning	2-8
2.4	Jogging	2-10
2.5	Torque regulation	2-11
2.6	Synchronous operation	2-12

2. Description of the functions with associated variables

2.1 General

Variable		Bit	Range	Comment
LADDR_I / LADDR_O	I	16	Address range	Projected I/O start addresses of the slave
EN_drive	I	1	0/1	1 = drive ON / 0 = drive OFF
EN_ok	O	1	0/1	Drive active. No fault
feed_constant	I	32	2 .. (2 ³¹ - 1)	Feed constant (in µm) see chapter A.1
init_flag	D	1	0/1	Must be deleted for initialisation
fault_reset	I	1	0/1	Reset fault (module and controller)
hold	I	1	0/1	Hold drive / abort function. Effect depends on operation mode
position_actual_value	O	32	(-2 ³¹)..(2 ³¹ - 1)	Actual position (in µm)
current_actual_value	O	16	(-2 ¹⁵)..(2 ¹⁵ - 1)	Actual motor current (in 1/1000 x nominal motor current)
digital_inputs	O	8	0 .. 255	Digital inputs of the controller (see chapter 3.1)
error	O	16	0 .. 127	Error bits (see chapter 3.1)

Fig. 2/2:

2.1.1 LADDR_I / LADDR_O

The slave I/O addresses of the respective controller are automatically assigned using Step7 during configuration of the hardware.

2. Description of the functions with associated variables

2.1.2 EN_drive / EN_ok

The **EN_drive** input enables the drive and the module functions.

In order for this to happen, the drive enable logic must be parameterised to "Input Din5 plus fieldbus" in the controller and the digital input 5 must be supplied with 24 V.

The **EN_ok** output indicates that the drive is operating and that there are no faults.

2.1.3 feed_constant

The **feed_constant** variable informs the controller of the feed distance in μm covered by the axis during one motor revolution. Any gear conversion ratio must be taken into consideration.

For example:

axis = DGE-25-750-ZR (63 mm feed), motor = MTR-AC-70-GA (i = 4).

Feed constant = 15750 μm .

For the standard values see Appendix A.

The controller uses this information to convert the remaining position parameters so that the following units can be used:

- Position specifications,
actual position = μm
- Speeds = $\mu\text{m/s}$
- Acceleration = $\mu\text{m/s}^2$

The feed constant is read in once upon initialisation of the module.

2. Description of the functions with associated variables

2.1.4 init_flag

A marker is required in order to initialise the module and the associated controller. This marker is deleted the first time it is called (for example via OB100). Once initialisation has been performed the marker is set by the module. Resetting the marker allows a re-initialisation to be forced at any time. This variable must not be held at 'logical 0' by a fixed instruction.

2.1.5 Position_actual_value / current_actual_value / digital_inputs

These output variables are a constant source of the following status information:

- the actual position (in μm)
- the actual current (in $1/1000 \times$ nominal motor current)
- the signal status of the controller's digital inputs.

2. Description of the functions with associated variables

2.2 Homing

Variable	Bit	Range	Comment	
start_homing	I	1	0/1	Enables and starts homing
homing_method	I	8	1 . . 15	Homing method
home_offset	I	32	$(-2^{31})..(2^{31}-1)$	Offset of the reference position (in μm)
homing_speed_switch	I	32	$0..(2^{31}-1)$	Finds the speed switch [$\mu\text{m}/\text{s}$]
homing_speed_zero	I	32	$0..(2^{31}-1)$	Exits the speed switch [$\mu\text{m}/\text{s}$]
homing_acceleration	I	32	$0..(2^{31}-1)$	Acceleration / delay [$\mu\text{m}/\text{s}^2$]
home_complete	O	1	0/1	Homing successfully completed

Fig. 2/3:

The purpose of homing is to reset the positioning system. It is required only once following a power-on, but can be performed any number of times.

Homing is activated by setting the **start_homing** input. This input must remain set until homing is complete, otherwise it will be aborted.

Successful conclusion is indicated with the output **home_complete**. The output is reset with:

Start reference travel, fault bit 0, 1 or 3, new initialization.

Using the hold input to abort homing results in an error message

The **home_offset** variable can be used to move the machine zero point in a positive or negative direction relative to the reference point.

There are 15 different ways of determining the reference point.

2. Description of the functions with associated variables

2.2.1 Methods of homing

No.	Direction	Target	Connec- tion	Reference point for zero position	Remarks on zero pulse
1	negative	Limit switch	(X1.22)	Zero pulse	<p>The resolver as actual-value sensor supplies absolute values within a revolution.</p> <p>It is not therefore necessary to make a movement in order to evaluate the zero impulse.</p> <p>The absolute value of the resolver position is simply added direction-related to the current position or accepted as the current actual position.</p> <p>Method 11 sets the position counter directly to 0.</p>
2	positive	Limit switch	(X1.10)	Zero pulse	
3	positive	Reference switch	(X1.11)	Zero pulse	
4	negative	Reference switch	(X1.11)	Zero pulse	
5	negative	Limit switch	(X1.22)	Limit switch	
6	positive	Limit switch	(X1.10)	Limit switch	
7	positive	Reference switch	(X1.11)	Reference switch	
8	negative	Reference switch	(X1.11)	Reference switch	
9	negative	No travel		Zero pulse	
10	positive	No travel		Zero pulse	
11		No travel		Current actual position	
12	positive	Stop		Stop	
13	negative	Stop		Stop	
14	positive	Stop		Zero pulse	
15	negative	Stop		Zero pulse	

Fig. 2/4:

2. Description of the functions with associated variables

2.3 Positioning

Variable	Bit	Bit	Range	Comment
new_set_point	I	1	0/1	executes new positioning profile
set_point_acknowledge	O	1	0/1	Handshake: 0 = new profile can be transferred, 1 = new profile has been transferred, but not yet executed
change_set_immediatly	I	1	0/1	New positioning profile will be executed: 0 = once the current profile has been processed, 1 = immediately; the current profile will be aborted
absolut_0_relativ_1	I	1	0/1	0 = absolute positioning, 1 = relative positioning
target_position	I	32	$(-2^{31})..(2^{31}-1)$	Positioning profile: target position [μm]
profile_velocity	I	32	$(-2^{31})..(2^{31}-1)$	Positioning profile: positioning speed [$\mu\text{m/s}$]
end_velocity	I	32	$(-2^{31})..(2^{31}-1)$	Positioning profile: final speed [$\mu\text{m/s}$]
profile_acceleration	I	32	$0..(2^{31}-1)$	Positioning profile: acceleration [$\mu\text{m/s}^2$]
profile_deceleration	I	32	$0..(2^{31}-1)$	Positioning profile: delay [$\mu\text{m/s}^2$]
position_ok	O	1	0/1	Drive is in target window
following_error	O	1	0/1	Following error

Fig. 2/5:

The **new_set_point** input must be set before the axis can move.

2. Description of the functions with associated variables

It transmits the positioning profile consisting of the target position, positioning speed, final speed, acceleration and delay to the controller. The controller must also be informed of whether the position is absolute or relative (incremental value).

The **position_ok output** is set once the profile has been processed and the drive is in the defined target window.

The final speed is usually zero. The speed at which the directly following positioning job is to be executed is only specified here if a so-called profile movement is to be executed. With individual positioning tasks this variable is not relevant.

As soon as one positioning profile has been transferred from the controller and executed, the next one can be transferred (**set_point_acknowledge output** is zero).

If the **change_set_immediately** input is not set, the second profile will be executed immediately upon completion of the first. If the input is set, the current profile will be aborted and the new one executed immediately.

The **following_error** output indicates that the difference between the actual position value and the target position value is too great. The reason for this could include the acceleration being too high, the current being too low or the load on the drive being too heavy. The following error is indicated exclusively via the output; no error message is generated.

Positioning can be aborted using the **hold** input. The specified **profile_deceleration** is used here.



Please note

Positioning mode is always active if no other function is selected. This means that the drive is always in position control mode, provided the drive is enabled and there are no errors.

If another function is activated while a positioning job is active, it will be aborted immediately.

2. Description of the functions with associated variables

2.4 Jogging

Variable	Bit	Range	Comment	
jogging_minus	I	1	0/1	Jogging in minus direction
jogging_plus	I	1	0/1	Jogging in positive direction
jogging_velocity	I	32	$(-2^{31})..(2^{31}-1)$	Positioning speed in jogging mode [$\mu\text{m/s}$]

Fig. 2/6:

Setting a **jogging_minus** or **jogging_plus** input moves the drive in the selected direction at a controlled speed. As soon as the respective input is reset, the drive brakes and returns to position control mode. The positioning profile data is transferred for the acceleration and braking ramps.

The speed in jogging mode is specified dynamically with the variable **jogging_velocity**.



Caution

A negative value inverts the direction function of the jogging buttons.

This function facilitates manual operation or setting operation. Since the current actual position is always available, it is also a simple way of realising teach-in operation.

The **hold** input sets the speed to zero.

2. Description of the functions with associated variables

2.5 Torque regulation

Variable	Bit	Range	Comment
enable_torque	1	0/1	Activates torque regulation
target_torque	16	$(-2^{15})..(2^{15}-1)$	Desired torque value in 1/1000 x nominal motor torque ¹⁾

¹⁾ The rated torque of a motor is derived from the parametrized rated current multiplied by the torque constant.

MTR-AC-55-3S	= 0,457	MTR-BSM-50	= 0,75
MTR-AC-70-3S	= 0,32	MTR-BSM-63	= 0,74
MTR-AC-100-3S	= 0,711	MTR-BSM-80	= 0,79
MTR-AC-100-5S	= 1,49	MTR-BSM-90	= 0,79

Example: motor MTR-AC-100-3S parametrized with 2.6 A rated current.
 Rated torque = 2.6 A × 0.711Nm/A = 1.85 Nm.
 0.9 Nm should be specified: $(1000 / 1.85 \text{ Nm}) \times 0.9 \text{ Nm} = 486$

Fig. 2/7:

If the **enable_torque** input is set, the controller supplies the motor with a constant current which it converts to a constant torque, without considering speed and position.

The torque value is specified by the **target_torque** variable in 1/1000 x nominal torque.

This results in sensible values in the range -1000 to +1000 (1000 = rated torque). Higher values can only have a short effect, as the I²t monitoring automatically regulates back to the rated current. The parametrized peak current cannot be exceeded.

The **hold** input holds the torque at zero.

The nominal torque value is passed over a ramp generator. The ramp time is 100 ms for a modification of 0 Nm on the rated torque.

At the end of the operating mode, the controller can be reset if Enable is switched off for approx. 100 ms.

2. Description of the functions with associated variables



Warning

As no speed control or limitation is effective here, the drive can reach non-permitted high speeds if no appropriate torque has a counter effect.

2.6 Synchronous operation

Variable	Bit	Range	Comment
enable_sync	1	0/1	Activates synchronous operation
encoder_resolution	32	4 . . 500000000	Encoder resolution at X10 in increments per revolution
encoder_numerator	16	$(-2^{15})..(2^{15} - 1)$	Numerator (conversion factor for encoder to motor revolution)
encoder_divisor	16	$(-2^{15})..(2^{15} - 1)$	Divisor (conversion factor for encoder to motor revolution)

Fig. 2/8:

In synchronous operation, the position controller is supplied with an additional desired position value via the connection X10.

This allows the drive to be connected as a slave to a master (by connecting input X10 Slave with output X11 Master), for example.

A further application is the "flying saw" function. This function is implemented by supplying the signal of an encoder at X10 which is connected to a conveyor belt, for example.

2. Description of the functions with associated variables

Activating synchronous operation via **enable_sync synchronises** the axis to the movement of the belt. As soon as the drive is in synchronicity with the belt (indicated by the **position_ok** output), the saw can be activated. Following the saw stroke, synchronous operation is deactivated once more and the saw is returned to its original position.

The ratio of encoder revolutions to motor revolutions is made known to the controller via the **encoder_numerator** and **encoder_divisor** variables so that the encoder can be adapted. The encoder resolution must also be made known via **encoder_resolution**.

Since the controller uses 16-bit arithmetic to perform the conversion of the encoder signals, there are certain restrictions when it comes to the resolution and the conversion factors. The following points must therefore be observed:
The encoder at X10 should have a binary increment, i.e. a resolution of 4096, for example.
Decimal increments (e.g. 4000) restrict the conversion factor range and result in rounding errors.

Synchronous operation is only permissible in parallel with positioning. No other function can be activated as long as synchronous operation is active. However positioning jobs can be performed while synchronous operation is active.



Please note

The synchronous operation variables for the encoder resolution and the conversion factor are transferred once to the controller during initialisation of the module. If these are changed while the module is active, it must be re-initialised.

2. Description of the functions with associated variables

Adjust parameters

Chapter 3

3. Adjust parameters

Contents

3.	Adjust parameters	3-1
3.1	Bit mappings of the output variables	3-3
3.1.1	8-bit output variable "digital_inputs"	3-3
3.1.2	16-bit output variable "error"	3-3
3.2	Notes on Profibus mode	3-4
3.3	Rotary axis	3-5
3.3.1	Procedure	3-5
3.3.2	Notes on application	3-6
3.4	Direct access to individual parameters in the controller	3-7

3. Adjust parameters

3.1 Bit mappings of the output variables

3.1.1 8-bit output variable "digital_inputs"

Bit	Function		X1-Pin
0	Negative limit switch actuated	Irrespective of normally-open or normally-closed contact	22
1	Positive limit switch actuated		10
2	Status sample input	Irrespective of normally-open or normally-closed contact Reference switch	11
3	Target selector POS0	The standard functions of these inputs are deactivated in Profibus mode	19
4	Target selector POS1		7
5	Target selector POS2		20
6	Target selector POS3		8
7	Start input		23

Fig. 3/1:

3.1.2 16-bit output variable "error"

Bit	Message	
0	Return error SFC14	Possible causes: incorrect slave address, slave not ready to operate, bus interruption. Specific fault code in Instance-DB, address 138 / 140
1	Return error SFC15	
2	Hardware input, output stage enable or drive enable missing	
3	Controller in error state (error shown on controller display)	
4	Drive enable logic in controller not set to BUS	
5	Reference travel started with invalid method	
6	Invalid feed constant during initialization	

Fig. 3/2:

3. Adjust parameters

3.2 Notes on Profibus mode

Once a drive has been parameterised, optimised and commissioned using the parameterisation software, the Profibus DP interface must be activated and the bus address specified. This is also done using the parameterisation software via the **"Transfer"** command in the **"File"** menu.

- The following configuration command must be entered in the Transfer dialog box:
BUS:NN:0000:1000

NN specifies the slave address in hexadecimal form, the value 1000 activates the bus.

- The following command must be entered to deactivate the bus:
BUS:NN:0000:0000
Transfer using **Enter** or **"Send"**

The bus configuration can be queried using **BUS?**

Once parameterisation has been completed and the bus activated, do not forget to back up the parameters (in the controller) and transfer the parameter record to a data volume. This means that a substitute controller can be immediately commissioned on the bus at any time simply by transferring the parameter record.

3. Adjust parameters

3.3 Rotary axis

If a rotary axis is to be dimensioned circularly, this can be carried out with the following two steps:

1. Adapt the feed constant.
The feed constant no longer specifies the feed in 1/1000 mm but in 1/1000 degrees for a motor revolution. The unit for positioning is therefore 1/1000 degrees.
2. Limit the positioning range (via RS232).
The positioning range is defined by specification of a lower and upper limit, e.g. 0 to 360.000 degrees. If a limit value is exceeded, the position counter will jump automatically to the other limit value.

3.3.1 Procedure

The range limits are defined with Object 607Bxx (application see chapter 3.4).

The lower limit with 607B01; the upper limit with 607B02 (parameters 32 bits each).

The range limits are activated with Object 651020 (parameter 16 bits).

The feed constant is transferred to the FB with the input variable **feed_constant**.

Example

A motor with gears $i = 4$ drives a rotary gripper by means of a toothed belt with the ratio 3 to 1. The total ratio is $3 \times 4 = 12$. The value $360000 / 12 = 30000$ [1/1000 degrees] is specified as feed constant (1 motor revolution \triangleq 30,000 degrees gripper revolution).

3. Adjust parameters

Limit positioning range by means of RS232 commands

Lower limit (0)	=607B01:00000000
Upper limit (360000)	=607B02:00057E40
Activate limits	=651020:0001
(deactivate)	=651020:0000)

Feed constant

feed_constant: =L#30000

3.3.2 Notes on application

If referencing is necessary, a method with a separate reference switch must be selected. Limit switches are not possible on a rotary axis which moves through more than 360 degrees. As an alternative, the zero impulse can be used as the reference point, providing there is a total ratio of 1.

Absolute positioning can be made within the 360 degrees, whereby the shortest path will automatically be traversed.

With relative positioning, paths of any desired length are possible (multiples of 360 degrees). The direction of rotation is determined by the sign in front of the length specification.

Positioning over several revolutions with absolute target within the circle must be carried out in two steps:

1. number of relative revolutions, 2. absolute circle position.

However, if it must be assured that absolute positioning always take place in the same direction, we recommend that the total positioning path be calculated from the current position and that the complete path be traversed relatively.

3. Adjust parameters

3.4 Direct access to individual parameters in the controller

The parameters of the controllers are addressed via objects. These objects are identified by an index and a subindex. A listing and description of the objects can be found in the PRO-FIBUS-DP product handbook.

These objects can be read and written to via the serial interface. For example using the parameterisation software in the Transfer dialog box (menu: **File / Transfer . .**). This means that objects which cannot be reached via the standard functions in the parameterisation software or the functional block can be used.

Written form

Read Object: ?XXXXSI
Write Object =XXXXSI:WWWWWWWWW

XXXX	Index of the object (hexadecimal).
SI	Subindex of the object (hexadecimal). Subindex 00 is optional.
WW	Value of the object (8 bit hexadecimal).
WWWW	Value of the object (16 bit hexadecimal).
WWWWWWWWW	Value of the object (32 bit hexadecimal).

If the bit width of the object value is not known, it is recommended to first read out the object. The length is correctly output in the response.

Example Read

=607B01	Answer: =607B01:00004E20
=651020	=651020:0001

Example Write

=607D01:80000000
=604D:04 (the subindex 00 does not have to be specified)

3. Adjust parameters



Please note

- Modifications entered are effective immediately.
- Incorrect entries or modifications to non-permitted Objects can result in malfunctioning or serious faults.
- Before issuing a write command check that the address is correct (Index, Subindex), in order that an incorrect Object is not overwritten by mistake.



Please note

The following applies here also:
if parameters were changed, they must be backed up so that they remain permanently effective. (menu: Parameters / Back up parameter record).

Appendix A

A. Technical Appendix

A. Technical Appendix A-1

A.1 Standard feed constants of the Festo linear drives with servo motors type MTR-AC-...

Size	Type	Motor with/without gears MTR-AC-...-A MTR-AC-...-G	Feed constant [μm]
Spindle axis			
18	DGE-18-...-SP-...	Without gears	4000
25	DGE-25-...-SP-...	Without gears	10000
40	DGE-40-...-SP-...	Without gears	20000
	DGE-40-...-SP-...	With gears $i = 4$	5000
63	DGE-63-...-SP-...	Without gears	30000
	DGE-63-...-SP-...	With gears $i = 4$	7500

Fig. A/3:

A. Technical Appendix

Size	Type	Motor with/without gears	Feed constant [μm]
		MTR-AC-...-A MTR-AC-...-G	
Toothed belt axis			
18	DGE-18-...-ZR-...	Without gears	52000
25	DGE-25-...-ZR-...	Without gears	63000
	DGE-25-...-ZR-...	With gears $i = 4$	15750
40	DGE-40-...-ZR-...	Without gears	100000
	DGE-40-...-ZR-...	With gears $i = 4$	25000
63	DGE-63-...-ZR-...	Without gears	176000
	DGE-63-...-ZR-...	With gears $i = 4$	44000
18	DGEA-18-...-ZR-...	Without gears	81000
	DGEA-18-...-ZR-...	With gears $i = 4$	20250
25	DGEA-25-...-ZR-...	Without gears	81000
	DGEA-25-...-ZR-...	With gears $i = 4$	20250
40	DGEA-40-...-ZR-...	Without gears	120000
	DGEA-40-...-ZR-...	With gears $i = 4$	30000
25	DGE-25-...-RF-...	Without gears	90000
	DGE-25-...-RF-...	With gears $i = 4$	22500
40	DGE-40-...-RF-...	Without gears	125000
	DGE-40-...-RF-...	With gears $i = 4$	31250
63	DGE-63-...-RF-...	Without gears	232000
	DGE-63-...-RF-...	With gears $i = 4$	58000

Fig. A/4: