

**Axial kit
EAMM-A-D...-...A/P**

1. Intended use

Axial kit EAMM-A-D...-...A/P:
Connecting an axis to a motor in axial configuration to the driven shaft
(→ section 9).

2. Safety instructions and notes on mounting



Warning

Unexpected movement of components.
Injury due to electric shock, impact, squeezing.
• Switch off power supply before mounting work.
• Observe the safety instructions (→ applicable documents).

Note

Incorrect mounting can cause malfunction and material damage.
• Select correct screw length¹⁾ of the screws [6].
• Observe tightening torques (→ section 7).
• Leave lubricant film on the screws.
• Clean shafts. The coupling [1] only grips dry and grease-free drive shafts.
• Observe alignment of the coupling hubs (→ section 6).
• Support combination (→ section 8):
– if there are far-protruding and heavy motor attachments
– in the event of severe vibrations and oscillation/shock loads.
Each time after disconnecting or turning the motor:
• Perform homing of the axis.


Information

Applicable documents

→ Motor operating instructions
→ Axis operating instructions
The kit contains the maximum mounting attachments that may be required.
• Select required mounting components (→ section 7).


3. Parts lists

3a. EAMM-A-D19/D32-28A/-40A/-40P/-42A




- [1] Coupling hub (2x)
- [2] Clamping screw (2x)
- [4] Coupling housing (1x)
- [6] Screw¹⁾ (4x)
- [8] Motor flange (1x)
- [9] Screw (4x)
- [11] Screw (4x)

3b. EAMM-A-D...-...A/P




- [1] Coupling hub (2x)
- [2] Clamping screw (2x)
- [4] Coupling housing (1x)
- [6] Screw¹⁾ (4x)
- [8] Motor flange (1x)
- [9] Screw (3x/4x)
- [11] Screw (4x)


4. Preassembly of the coupling




- Pull apart the coupling.
- Press the ring gear (A) onto one of the two coupling hubs [1].
- Screw on clamping screws [2].




- Push the coupling hub [1] with the matching drill hole onto the drive shaft (B).
(D) EHMB, ERMB
(E) DNCE, EGSL, ESBF



- For accurate alignment:
- Maintain distance (X) (→ section 6).
 - Tighten clamping screw [2].




- Push the coupling hub [1] with the matching drill hole onto the drive shaft (C).




- For accurate alignment:
- Maintain distance (Y) (→ section 6).
 - Tighten clamping screw [2].

5. Mounting


5a. Mounting DNCE, EGSL, ESBF




- Without foot mounting:
- Fasten the coupling housing [4] to the axis with the screws [6]¹⁾.



- With foot mounting HNCE (F)²⁾:
- Fasten the coupling housing [4] and foot mounting (F) to the axis with the screws [6]¹⁾.




- Fasten the motor flange [8] to the coupling housing [4] with all screws [9].




- Push motor and the axis together.
Check: correct position of the coupling hubs [1] in relation to each other.
- Fasten the motor to the motor flange [8] with the screws [11]³⁾.


5b. Mounting EHMB, ERMB



- Fasten the coupling housing [4] to the axis with the screws [6]¹⁾.



- Fasten the motor flange [8] to the coupling housing [4] with all screws [9].




- Push motor and the axis together.
Check: correct position of the coupling hubs [1] in relation to each other.
- Fasten the motor to the motor flange [8] with the screws [11]³⁾.

6. Alignment of the coupling hubs [1]

Note

Axial forces on the shafts of motor and axis can result in failure of the encoder/brake or increased wear on the bearings.
• Maintain the distances X and Y.



EAMM-A-	Y ₁ ^{±0,5} [mm]	X ₁ ^{±0,5} [mm]	Y ₂ ^{±0,5} [mm]	X ₂ ^{±0,5} [mm]	Z [mm]
D19-28A	19,7	18,5	-	-	-
D19-40A	16,2		-	-	-
D19-40P	19,2		-	-	-
D19-42A	23,5	16,7	-	18,7	4
D32-40A	15,1		17,1	-	
D32-40P	19,3		21,3	-	
D32-42A	23,3	18,2	25,3	-	4
D32-55A	19,6		21,6	20,2	
D32-57A	20,9		22,9	-	
D32-60P	30,1	18,7	32,1	-	4
D32-67A	25		27	-	
D40-55A	19,1		21,1	20,7	
D40-57A	20,4	18,7	22,4	-	4
D40-60P	29,6		31,6	-	
D40-67A	24,5		26,5	-	
D40-70A	21,9	27,7	23,9	-	5
D40-87A	23,9		25,9	-	
D50-70A	24,5		-	-	
D50-80P	36	23,5	-	-	5
D50-87A	26		-	-	
D50-100A	39,5		-	-	
D60-70A	23,7	23,5	26,2	26	5
D60-80P	35,2		37,7	-	
D60-87A	25,2		27,7	-	
D60-100A	38,7	33,5	41,2	-	5
D80-100A	40,3		-	-	
D80-140A	50,3		-	-	
D100-100A	40,2	41,1	-	-	5
D100-140A	48,4		-	-	

¹⁾ The screws [6] are labelled correspondingly.


²⁾ Only with DNCE

³⁾ For EAMM-A-D...-...-42A, the motor flange [8] is fastened to the motor with the screws [11].

7. Screw sizes and tightening torques M_A ⁴⁾

EAMM-A-	[2]	[Nm]	[6 ⁵⁾	[Nm]	[9]	[Nm]	[11]	[Nm]	
D19-28A	M2x6	0,5	M4x16	2,5	M3x12	1,2	M2,5x8	0,6	
D19-40A					M3x16		1,2		
D19-40P					M3x10				
D19-42A					M3x12				
D32-40A ⁶⁾	M2x6	0,5	M6x20	5/6 ⁷⁾	M3x14	1,2	M3x14	1,2	
D32-40P ⁶⁾					M3x12		M3x12		
D32-42A					M3x20		M3x10		
D32-55A	M4x12	4	M6x22/M6x30 ¹⁾	5/6 ⁷⁾	M4x12	2,4	M5x18	6	
D32-57A					3		M4x12		3
D32-60P							M4x20		
D32-67A					M4x12		M6x16		8
D40-55A					M4x12		4		M6x30
D40-57A	3	M4x12	3						
D40-60P		M4x20		M4x16		3			
D40-67A	M4x12	M6x16	8						
D40-70A	2,4	M5x18	6						
D40-87A		M4x16	3	M6x22		10			
D50-70A	M5x18	8	M8x50	12	M6x12	8	M5x20	6	
D50-80P					M6x16		10		
D50-87A					M8x50		M6x22		10
D50-100A					M8x65		M6x20		M8x25
D60-70A	M5x18	8	M8x22/M8x30 ¹⁾	9/ 12 ⁸⁾	M6x12	8	M5x20	6	
D60-80P					M6x16		10		
D60-87A					M8x22/M8x30 ¹⁾		M6x22		10
D60-100A					M8x33/M8x40 ¹⁾		M6x20		M8x25
D80-100A	M6x20	15	M10x70	25	M6x20	10	M8x20	18	
D80-140A					M6x25		M10x35		30
D100-100A	M6x20	15	M10x80	25	M6x20	10	M8x20	18	
D100-140A					M8x25		35		M10x35

8. Support of the axis-motor combination



To avoid damage:

- Support the combination so it is free from tension.

9. Permissible axes and motors

→ Note

Malfunction and material damage due to overloading.

The output variables of the motor must not exceed the permissible values of the components used.

Permitted values → www.festo.com/catalogue

- Limit motor output variables accordingly.

- Derive the axis and motor from the interface codes.

Example: EAMM-A-**D40-42A**

- Axis interface **D40**
- Motor interface **42A**

Axis interface	Axis ⁹⁾
D19	EGSL-35
D32	DNCE-32, ESBF-32, EGSL-45, EHMB-20 ⁶⁾ , ERMB-20 ⁶⁾
D40	DNCE-40, ESBF-40, EGSL-55, EHMB-25, ERMB-25
D50	ESBF-50
D60	DNCE-63, ESBF-63, EGSL-75, EHMB-32, ERMB-32
D80	ESBF-80
D100	ESBF-100

Motor interface	Motor ¹⁰⁾
28A	EMMS-ST-28
40A	EMMS-AS-40, MTR-AC-40
40P	EMME-AS-40
42A	EMMS-ST-42, MTRE-ST-42
55A	EMMS-AS-55, MTR-AC-55
57A	EMMS-ST-57
60P	EMME-AS-60
67A	EMCA-EC-67
70A	EMMS-AS-70, MTR-AC-70
80P	EMME-AS-80
87A	EMMS-ST-87
100A	EMME-AS-100, EMMS-AS-100, MTR-AC-100
140A	EMMS-AS-140

⁴⁾ Tolerance for tightening torques M_A without indication of tolerance $\pm 20\%$

⁵⁾ Do not exceed the tightening torque of the screw [6]. Otherwise, the cover screws of the axis will loosen during disassembly.

⁶⁾ EAMM-A-D32-40A/40P is not permissible for ERMB/EHMB-20.

⁷⁾ For DNCE-32/-40, EGSL-45/55: 5 Nm
For EHMB-20/25, ERMB-20/-25, ESBF-32/40: 6 Nm

⁸⁾ For DNCE-63, EGSL-75: 9 Nm
For EHMB-32, ESBF-63, ERMB-32: 12 Nm

⁹⁾ Rotary-linear module EHMB, rotary module ERMB, electric cylinder DNCE/ESBF, mini slide EGSL

¹⁰⁾ Servo motor EMME-AS/EMMS-AS/MTR-AC, stepper motor EMMS-ST/MTRE-ST, motor unit EMCA-EC