Updating the Base Unit

1. Ensure the host device is connected to the Base Unit.

2. On the host device, open a browser and access the Base Unit by entering the URL including the serial number of the Base Unit. Here is an example of URL where the serial number of the Base Unit is G123456:

   https://electeoG123456.local

3. Open the Base Unit Settings.

   

   A password may be required. The default password for the Base Unit is "FestoPass123".

4. Press the blue "Update" button.

5. Select the downloaded ".sig" file.

6. Press the "OK" button to start the update process. A pop-up will appear on the screen to let the user know that the transfer has started.

   

   For a normal update, the update process takes about 1 minute. However, if the update contains important components of the operating system, it may take much longer.

   When the transfer is complete, a popup will appear indicating that the Base Unit is updating. At this point the Base Unit status LED strip will start flashing rapidly in yellow until the update is complete.

   Once the update process completed, the Base Unit will shut down completely.

7. Close all the browsers. The Base Unit is now up to date and ready to be started up again.

© Festo Didactic