Application Note



Commissioning VPPX in FCT

VPPX

Title	Commissioning VPPX in FC1
Version	<u> </u>
Document no	
Original	
Author	Festo
Last update	21.01.2019

Copyright Notice

This documentation is the intellectual property of Festo AG & Co. KG, which also has the exclusive copyright. Any modification of the content, duplication or reprinting of this documentation as well as distribution to third parties can only be made with the express consent of Festo AG & Co. KG.

Festo AG & Co KG reserves the right to make modifications to this document in whole or in part. All brand and product names are trademarks or registered trademarks of their respective owners.

Legal Notice

Hardware, software, operating systems and drivers may only be used for the applications described and only in conjunction with components recommended by Festo AG & Co. KG.

Festo AG & Co. KG does not accept any liability for damages arising from the use of any incorrect or incomplete information contained in this documentation or any information missing therefrom.

Defects resulting from the improper handling of devices and modules are excluded from the warranty.

The data and information specified in this document should not be used for the implementation of safety functions relating to the protection of personnel and machinery.

No liability is accepted for claims for damages arising from a failure or functional defect. In other respects, the regulations with regard to liability from the terms and conditions of delivery, payment and use of software of Festo AG & Co. KG, which can be found at www.festo.com and can be supplied on request, shall apply.

All data contained in this document do not represent guaranteed specifications, particularly with regard to functionality, condition or quality, in the legal sense.

The information in this document serves only as basic information for the implementation of a specific, hypothetical application and is in no way intended as a substitute for the operating instructions of the respective manufacturers and the design and testing of the respective application by the user.

The operating instructions for Festo products can be found at www.festo.com/sp.

Users of this document (application note) must verify that all functions described here also work correctly in the application. By reading this document and adhering to the specifications contained therein, users are also solely responsible for their own application.

© (Festo AG & CO. KG, D-73726 Esslingen, 2019)

Internet: http://www.festo.com

E-Mail: service international@festo.com

Table of contents


1	Hardware/Software	5
2	FCT application	6

1 Hardware/Software

Install FCT and plug in:


It is possible that you need administrator rights.

https://www.festo.com/net/nl-be_be/SupportPortal/default.aspx?q=fct&tab=4




• Connect the VPPX with your PC.


570971 VAVE-P8-VPS 547432 NEFC-M12G5-0.3-U1G5



2 FCT application

- Open FCT
- Verify COM port





COM Port:


Bitrate:


57600


OK

Cancel


Extract the project.








• Change, download, save settings



• Save project and Archive project.



• Go Offline & disconnect

